

Telephone dialer TD-101 / TD-101W

- *description*
- *installation*
- *setting*
- *use*
- *examples*



JABLOTRON

Pod Skalkou 33
466 01 Jablonec nad Nisou
Czech Republic

E-mail : export@jablotron.cz
<http://www.jablotron.cz>




JABLOTRON

Contents :

1. Description	3
1.1. Possibilities of use	3
2. Specifications	3
3. TD-101 includes	4
4. Installation	4
4.1. Terminal Description	4
5. Operation	4
5.1. What does the dialer do if activated	4
6. Voice & pager messages setting	6
6.1. How to open USER MODE	6
6.2. Entering telephone numbers for voice messages sending	6
6.3. Voice messages recording	6
6.4. Entering telephone numbers and data for PAGER	7
6.5. Deleting telephone numbers	7
6.6. Remote control code learning (<i>only for model TD-101W</i>)	7
6.7. Erasing of remote controls (<i>only for model TD-101W</i>)	7
6.8. Testing the message sending	8
6.9. Changing of the User Code	8
7. Monitoring station data sending	10
7.1. Opening of Installer Mode for monitoring station data programming	10
7.2. Entering telephone numbers of Monitoring Station	10
7.3. Deleting of Monitoring Station telephone numbers	10
7.4. Monitoring station Communication Protocol & Format setting	11
7.5. Account number programming	11
7.6. Reporting codes programming	11
7.7. Testing the Monitoring Station communication	12
8. Optional functions and parameters programming	12
8.1. Opening of Installer Mode for Optional functions programming	12
8.2. Dialing method	12
8.3. Number of voice messages	12
8.4. Trigger inputs IN1 and IN2 logic	13
8.5. Trigger delay	13
8.6. Number of cycles to send voice & Pager messages	13
8.7. Number of attempts to call Monitoring Station	14
8.8. Telephone line signals detection	14
8.9. Audible function monitor (built in speaker)	14
8.10. Stop function with Ekey	15
8.11. Emergency triggering with Fkey	15
8.12. Changing of the Installer Code	15
8.13. Factory default reset	15
9. Trouble shooting	16
9.1. Emergency reset	16
10. Programming diagrams	
Voice & Pager messages and telephone numbers setting	17
Optional functions and parameters programming	18
Monitoring Station data setting	19
11. Examples of TD-101(W) use	20
11.1. Trigger inputs IN1 and IN2 connection	20
11.2. Use of the dialer only for emergency dialing (old or ill people)	20
11.3. Example of TD-101(W) use with different alarm systems	21

Drilling diagram of TD-101(W)



Conformity:

Hereby, Jablotron Ltd., declares that this TD-101(W) is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Original of the conformity assessment can be found at the web page www.jablotron.cz, section Technical support.

Notes :

Although this product does not contain any harmful materials we suggest you to return the product to the dealer or directly to the producer after usage.

1. Description

The TD-101 is an automatic dialing device that transmits prerecorded information via the telephone line. The dialer can send two different 10 second voice messages (or one 20 second message) to four phone numbers. It can also send two different Numeric messages to two different PAGERS and four digital codes to a monitoring station. The desired type of communication is easily selected during installation.

The dialer has two trigger inputs. The optional model TD-101W can also be triggered remotely with a wireless remote control.

There are three levels of operation for the TD-101: *standby*, *user*, and *installer*. Three light emitting diodes on the front of the TD-101 show what level the dialer is in.

In *standby* mode the TD-101 waits for an input from either of the trigger inputs or from the built in keypad.

At the *user* level (accessible with User Code) you can enter and delete phone numbers, change the voice messages, change the user code, or test that the TD-101 is functioning properly. Model TD-101W can also "learn" a remote control code in this level.

At the *installer* level (accessible with Installer Code) you can modify optional functions of the dialer and enter data for digital communication with a monitoring station.

All data is stored in the TD-101's EEPROM memory. So disconnecting the power from the dialer will not erase the data. An emergency reset feature can return the dialer to its original factory settings when necessary.

The autodialer takes priority on your telephone line. When triggered, it will switch all other devices (phone, fax, PABX) off line. By checking signals on the line (dial, busy or ringing tone) the dialer knows what its next response should be. A built in speaker can be used as an audible monitor of the dialer function. The telephone line is electrically separate from the power and trigger inputs. The TD-101 has specially designed circuits to protect your telephone line from lightning strikes overvoltage. Tamper protection is also provided.

1.1. Possibilities of use

The TD-101 dialer has a wide spectrum of use:

- **property protection** - connected with a house alarm system it can send not only an alarm message, but also arm/disarm information or panic signal
- **emergency calls** - ill or old people can easily call a doctor or relatives for help using the TD-101. The dialer can be triggered by pressing the F key, or by an additional push button wired to the input. Model TD-101W can also be triggered with a wireless remote control.
- **technical information sending** - the dialer can automatically report failures of crucial devices (refrigerator, cooling systems, pumps, heating systems, elevators etc.) or in connection with a suitable sensor it can inform about reaching of a critical level of controlled parameters (temperature, humidity, water level etc.).

2. Specifications

operating voltage	12VDC (10-14V)
current consumption	stand by 15 mA max. operating 100 mA max.
trigger inputs	IN1 & IN2 separated with optocouplers option TD-101W also wireless 1A / 60V max.
tamper switch	electrically separated, over voltage protection
telephone line	pulse / tone
dialing method	
phone number Memories	voice message 4x 16 digits (Mem1-4) pager 2x 26 digits (Mem5,6) monitoring station 2x 16 digits (Mem7,8)
phone line signal detection	dialing, busy or ringing tone
voice message duration	2x 10 or 1x 20sec.
monitoring station protocols	ADEMCO, SILENT KNIGHT, SESCOA, FRANKLIN, DCI, VERTEX, RADIONICS, DTMF 1400, DTMF 2300



can be connected to analogue interfaces TBR 21/1998, EG 201 121 V1.13/2000, AS/ACIF S002/2001 (Australia)

3. TD-101 includes

the dialer, 2.5m telephone cable, set of screws, manual, and emergency F button marking label. Model TD-101W, in addition, includes a wireless remote control (RC-10)

4. Installation

We recommend professional installation of the dialer. The dialer should be fixed in the desired location using the two included screws (see drilling diagram at the end of this manual). First, partially screw in the top screw and slide the screw head through the hole in the upper part of the TD-101 rear panel. Then open the dialer terminal compartment cover and mark the position of the second screw. Place cables through the hole for cables in the rear panel before installing the second screw. Do not open the upper part of TD-101 housing during installation; doing so will result in voiding of warranty.

4.1. Terminal Description

- IN

OUT

+12V, GND

TAMPER

IN1 +/-

IN2 +/-
- telephone line input (inlet of the telephone line to the house)


telephone line output (phone, fax etc.); in the stand by mode the line operates as normal. If triggered, the TD-101 will use the line (switch off the other devices)

external power supply (12VDC, max. 100mA)

tamper switch (normally closed contacts)

positive and negative poles of the first trigger input

positive and negative poles of the second trigger input



Terminals TD-101 (W)

5. Operation

When power is supplied, the dialer will perform an automatic self test (red LED turns on for 10 seconds). Then the TD-101 will enter the stand by mode. In this mode, the TD-101 is waiting for an input from either the keypad or the trigger inputs. For correct function of the dialer, the telephone numbers and messages must first be programmed (see chapter 6.).


5.1. What does the dialer do if activated:

- seizes the telephone line (switches off all other devices)
- checks dial tone, if the tone is not detected, it will try to release the line again
- dial the first tel. number and if detects:
 - **ringing tone**, it will send the message and will not call this number again
 - **busy signal**, it will call next number and then will try to call the previous number again

The red LED will light when the dialer has been triggered. Once the dialer has been triggered, it's dialing procedure can be terminated by pressing and holding the E key (if enabled in installer level). This is possible only when the IN1 and IN2 inputs are not triggered.



11.3. Example of TD-101(W) use with different alarm systems



Suggestion of programming for the configuration above


user mode setting	tel. number memories Mem	1, 2 - not used
		3, 4 - numbers for alarm voice message
		5 - not used
		6 - alarm PAGER number and data
installer mode setting	record only voice mess. no. 2	
	data for Monitoring Station	
	four report codes can be programmed	disarming arming
	(see chapter 8)	alarm end of alarm
	logic of IN1 and IN2 inputs	Normally Closed contacts

11. Examples of TD-101(W) use

The dialer inputs are separated with optocouplers, so the variety of possible connections is really wide. The following examples are only for your reference. Other connections and settings are also possible to meet your requirements. Ask you distributor if you need any advice regarding the TD-101 installation or programming.

11.1 Trigger inputs IN1 and IN2 connection

The input optocoupler is switched on, if its voltage is from 5 to 20V, minimal trigger signal duration must be 0.1 sec.




11.2. Use of the dialer only for emergency dialing (old or ill people)

Connect the dialer to the telephone line (between the wall plug and the telephone set). Use an adapter with output voltage 12VDC, min. 100mA to power the dialer (wire the adapter to +12V and GND terminals, mind the polarity).

Enter the user mode (see chapter 6.) to program the telephone numbers for the voice message to memories **Mem3** and **Mem4**. You can also program a Pager number & data which should be displayed to memory **Mem6**. Then record voice message no. 2 and return to the stand by. Now the dialer is ready for emergency calls.

It can be triggered with the **F**key (use an adhesive sticker to make it more visible). Model TD-101W can also be triggered by remote control. An additional push button (installed by the patient's bed for example) can be wired to the dialer input IN2 (see the first diagram above - normally open contact trigger).

Voice and pager message sending description



6. Voice & pager messages setting

Phone numbers, voice messages and Pager numbers & messages can be set in the USER MODE

6.1. How to open USER MODE

Enter User Code (factory setting is 1234) to open the user mode. The user mode is indicated by the green LED.

All parameters are programmed in the following sequences. If the first key of the sequence is entered, the red LED will start to flash. When the sequence is completely entered, the red LED will turn off (data will be stored). A started sequence entering can be terminated by pressing the **E** key at any time.

After all programming the user mode must be finished by pressing the **E** key (all the LEDs will turn off). The dialer can not be activated in the user level !

6.2. Entering telephone numbers for voice messages sending

Telephone numbers can be entered in the user mode (the green LED is ON - see 6.1.). The dialer has 4 memories **Mem1** to **Mem4** which are for voice messages dialing. Telephone numbers can be entered including an area code number for long distance calls. The dialer can also be used to call a mobile phone. To program telephone numbers, enter :

☎☎☎☎ ... ☎ M†

where:

☎ is a telephone number, keys **□** to **☎** or **+** i.e. pause. Pause can not be in the first position. Keys **■** and **○** can also be programmed in tone dialing mode. Each telephone number can have up to 16 digits.

† indicates into which memory (1 to 4) the tel. number will be stored.

When **IN1** is triggered, voice **message no 1** is sent to **Mem1** and **Mem2**; when **IN2** is triggered, **message no. 2** is sent to **Mem3** and **Mem4**. Remote control button or **F** key pressing has the same effect as IN2 triggering. If both inputs, IN1 and IN2, are triggered simultaneously, the dialer will react the same way as the IN1 is triggered at first and the IN2 after that.

Example: Telephone number 02 311603 will be stored into memory **Mem2** .

☎ + ☎☎☎☎☎ M■

6.3. Voice messages recording


Voice messages can be recorded in the user mode (the green LED is ON - see 6.1.). To record a message, enter:

M†

where:

† is the message number **□** or **■** - press and keep down the number key while speaking in to the microphone (max. 10 sec). The message will be played back automatically for 40 seconds when you release the button (can be stopped with **E** key). The voice messages can also be played in stand by mode, after entering **M□** for the first and **M■** for the second message.

Note: If only one message (20 sec.) is selected in the installer level, record it as **message no. 1**.



6.8. Testing the message sending

Sending of voice & Pager messages can be tested in the user mode (the green LED is ON - see 6.1.), entering:

FM†

where:

† is the tel. number memory 1 to 6 in which the corresponding message will be sent. If you enter 0 all tel. numbers will be tested. Testing is always audible (you can hear tel. line signals and voice messages from the built in speaker).

Example : Voice message no. 1 will be sent to tel. number Mem2 :

FM■

6.9. Changing of the User Code

To avoid non authorized access to the user mode, change the User Code for a new one. The code can be changed in the user mode (the green LED is ON - see 6.1.), entering:


M■ ■■■■ ■■■■

where :

■■■■ is your new user code (four digits). The new code must be entered twice to be changed (protection of accidental change). Original factory default setting of the User Code is 1234.

Example : The user code will be changed for code 2010 :

M■ ■■■■ ■■■■



7. Monitoring station data sending

Function of the TD-101 including the Monitoring Station (MS) communication is demonstrated in the diagram on page 9. Data is sent to the monitoring station before voice & Pager messages are sent (if these messages are used). All parameters of the MS communication should be programmed in cooperation with your monitoring service provider. Programming of the data for the MS is only possible in the Installer mode.

If you do not use the dialer to send data to a monitoring station, do not program anything in this section.

7.1. Opening of Installer Mode for monitoring station data programming

To enter Installer level from Standby, **enter Installer code IC press + and enter Installer Code IC again.** Factory default IC is 1010 so when you open the Installer mode for the first time, enter **0000 + 0000**. The installer level is indicated by the yellow LED.

All parameters are programmed in the following sequences. If the first key of the sequence is entered, the red LED will start to flash. When the sequence is completely entered, the red LED will turn off (data will be stored). A started sequence entering can also be terminated by pressing the **E**key at any time.

After all programming is finished, the Installer mode must be exited by pressing the **E**key (all the LEDs will turn off). The dialer can not be activated in the Installer level !

7.2. Entering telephone numbers of the Monitoring Station

Telephone numbers can be programmed in the Installer mode (the yellow LED is ON - see 7.1.), entering:

☎☎☎☎ ... ☎ M†

where:

☎ is a telephone number, keys **□** to **↵** or **+** (i.e. pause). Pause can not be on the first position, keys **■** and **○** can also be programmed in tone dialing mode. Each telephone number can have up to 16 digits.

† is the tel. number memory **7** = main tel. number (**Mem7**), **8** = alternate tel. number (**Mem8**). The alternate number is only called if the main number is busy.

Example: The main telephone number of the monitoring station will be 811 777 :

◆□□◆◆ M◆

7.3. Deleting of Monitoring Station telephone numbers

Telephone numbers for MS can be deleted in the installer mode (the yellow LED is ON - see 7.1.), entering:

+ M→

where:

→ is the memory number **7** or **8** which will be erased. If a number is erased, the corresponding dialing will not be performed.

Note: If both numbers for MS are erased, there will be no communication to the monitoring station

Example: Spare MS telephone number will be erased :

+ M◆

If Stop with **E**key is enabled, the TD-101 action can be stopped only if no input is triggered. The dialer action is terminated a few seconds after the **E**key is pressed.

If Stop is disabled, the communication can not be stopped before its end.

Example: The STOP will be disabled :

F↵

8.11. Emergency triggering with Fkey

Emergency trigger key can be enabled or disabled in the installer mode (the yellow LED is ON - see 8.1.), entering:

F□ ☎

where:

☎=0 emergency trigger disabled

☎=1 emergency trigger enabled (factory default setting)

If you use the **F**key as an emergency button, you can mark the key with an adhesive label which is included.

Note: The above setting does not have any effect to the remote control trigger of TD-101W model.

Example: Emergency trigger will be disabled :

F□

8.12. Changing of the Installer Code

To avoid non authorized access to the installer mode, change the Installer Code for a new one. The code can be changed in the installer mode (the yellow LED is ON - see 8.1.), entering:

M■ ☎☎☎☎ ☎☎☎☎

where :

☎☎☎☎ is the new installer code (four digits). The new code must be entered twice to be changed (protection of accidental change). The original factory default setting of the Installer Code is 1010.

Example : The user code will be changed for code 3112 :

M■ ◆□□◆ ◆□□◆

8.13. Duration of Pause in Pager dialing

Duration of the pause which is generated with the **F**key in pager number programming can be selected in the installer mode (the yellow LED is ON - see 8.1.) entering.

F F ☎

where :

☎=0 pause = 5 seconds (factory default)

☎=1 pause = 10 seconds

Example: 10 seconds Pause will be selected:

F F□

8.7. Number of attempts to call monitoring station

Number of attempts to call MS can be programmed in the installer mode (the yellow LED is ON - see 8.1.), entering:

F

is a number of attempts to call monitoring station, can be from 1 to 8. A successful communication handshake cancels all following attempts.
(factory default setting are 3 attempts)

Example: Five cycles will be selected :

F

8.8. Telephone line signals detection

Detection of signals can be enabled or disabled in the installer mode (the yellow LED is ON - see 8.1.), entering:

F

where:

=0 detection disabled

=1 detection enabled (factory default setting)

If the telephone line signals detection is **enabled**, the dialer will check for the dial tone at first. If a dial tone is not present, it will try to release the line again. Then it will dial the first stored number and if it gets a ringing tone, it will send the message once and it will not call this number again.

If the number is busy, it will dial the next number and the dialing will be repeated after that.

If the signals detection is **disabled**, the dialer will make as many cycles as programmed in F , no matter what the signals on the line are.

Example: Detection will be disabled :

F

8.9. Audible function monitor (built in speaker)

The built in speaker can be enabled or disabled to listen the dialing and calling. It can be selected in the installer mode (the yellow LED is ON - see 8.1.), entering:

F

where:

=0, disabled

=1, enabled (factory default setting)

The audible line monitoring with built in speaker is always enabled when you test the TD-101.

Example: The audible dialing monitor will be enabled :

F

8.10. Stop function with Ekey

Stop function is selectable in the installer mode (the yellow LED is ON - see 8.1.), entering:

F

where:

=0 stop is disabled

=1 stop is enabled (factory default setting)

7.4. Monitoring station Communication Protocol & Format setting

Protocol and format can be selected in the Installer mode (the yellow LED is ON - see 7.1.), entering:

M

where:

means protocol and means format, see the following table:

	protocol		format
0	ADEMCO / SILENT KNIGHT SLOW 10 BPS	0	3/1 not extended
1	SESCOA, FRANKLIN, DCI, VERTEX 20 BPS	1	3/2
2	SILENT KNIGHT FAST 20 BPS	2	4/1
3	RADIONICS (2300)	3	4/2
4	RADIONICS (1400)	4	3/1 extended
8	DTMF 1400		
9	DTMF 2300		

Example: SILENT KNIGHT FAST 20 BPS protocol and 4/1 format will be selected

M

7.5. Account number programming

Account number code can be entered in Installer mode (the yellow LED is ON - see 7.1.), entering:

M

where :

is the account number. If format 3/1 or 3/2 is selected (see 7.4. above) the first digit will not be sent.

Transmitted codes are usually „HEX“ data, i.e. each digit can be 0 to 15 (F). To enter HEX data, use key. Enter number 10(A) as , 11(B)= , 12(C)= , 13(D)= , 14(E)= , 15(F)= . Number 0 in account number **must be entered as** .

Example: Account number 12A5 will be stored :

M

7.6. Reporting codes programming

Reporting codes for activation and deactivation of the dialer inputs can be programmed in the installer mode (the yellow LED is ON - see 7.1.), entering:

M

where:

means event on the inputs, see following table:

input	activation	deactivation
IN1	3	4
IN2	5	6

is the report code for MS, (if = 00 is selected, this event will not be reported)

Transmitted codes are usually „HEX“ data, i.e. each digit can be 0 to 15 (F). To enter HEX data, use key. Enter number 10(A) as , 11(B)= , 12(C)= , 13(D)= , 14(E)= , 15(F)= .

Example: Code 3D will be reported if IN2 input is triggered :

M

7.7. Testing the Monitoring Station communication

Communication to the MS can be tested in the installer mode (the yellow LED is ON - see 7.1.), entering:

FM  **†**

where:

‡ is the tel. number memory **7** or **8** which will be called

† means event number (**3, 4, 5** or **6**) which code will be sent (see item 7.6.)

Example: Report code corresponding to IN2 input triggering (activation) will be sent to the main tel. number :

FM  

8. Optional functions and parameters programming

The settings chosen in the Installer mode can significantly customize the dialer operation. This programming should be done by a professional installer.

8.1. Opening of Installer Mode for Optional functions programming

To enter Installer level from the Standby, **enter Installer code IC press + and enter Installer Code IC again**. Factory default IC is 1010 so when you open the Installer mode for the first time, enter **□□□□ + □□□□**. The installer level is indicated by the yellow LED.

All parameters are programmed in the sequences started with **F**key. If a sequence is entered, the red LED will start to flash. When the sequence is completely entered, the red LED will turn off (data will be stored). A started sequence entering can also be terminated by pressing the **E**key at any time.

After all programming, the Installer mode must be exited by pressing the **E**key (all the LEDs will turn off). The dialer can not be activated in the Installer level !

Note: The installer code IC can also be used to open the user level, the same way as the User Code.

8.2. Dialing method

Pulse or tone dialing can be selected in the Installer mode (the yellow LED is ON - see 8.1.), entering:

F  **‡**

where:

‡ = 0 pulse

‡ = 1 tone (factory default)

The dialing method can also be changed from pulse to tone by entering **F** inside the phone number (it will insert a pause and it will switch to tone dialing); the **F**key can not be stored as the first digit.

Example: tone dialing will be selected

F 

8.3. Number of voice messages

One or two voice messages can be selected in the installer mode (the yellow LED is ON - see 8.1.), entering:

F  **‡**

where:

‡ means number of messages **1** = 1x 20sec. or **2** = 2x 10sec.
(factory default = 2 messages, max. 10sec. each)

If only one message is selected (max. 20sec.) :

- it should be recorded as message no. 1
- IN1 triggering will send the message to **Mem1** and **Mem2**
- IN2 triggering will send the message to **Mem3** and **Mem4**
- simultaneous triggering of IN1 and IN2 will send the message to all **Mem1** to **Mem4** tel. numbers
- Pager and monitoring station communications will not be effected
- to play the message in stand by press only the **M**key

Example: Only one voice message, max. 20sec. will be selected :

F 

8.4. Trigger inputs IN1 and IN2 logic

The method of IN1 and IN2 triggering can be selected in the installer mode (the yellow LED is ON - see 8.1.), entering:

F  **‡**

where:

‡ = 0 inputs are triggered if the input optocoupler current is switched off (N.C. trigger)

‡ = 1 input is triggered if the input optocoupler current is switched on (N.O. trigger)
(factory default setting is 1 = N.O. trigger)

Example: IN1 and IN2 will react to switching the current off (suitable for Normally Closed contacts)

F 

8.5. Trigger delay

The dialer reaction delay can be programmed in the Installer mode (the yellow LED is ON - see 8.1.), entering:

F  **‡**

‡ can be from 0 to 9, it means that the duration of the delay x10sec (i.e. 0 to 90sec.). Dialing will start with the delay only if the corresponding Input is triggered longer than the selected delay. If the input is deactivated before the delay time elapses, the dialer will not work. The delay is valid for all voice, Pager and Monitoring Station dialing.

*Note: triggering with F key or with the remote control (TD-101W) will always have no delay.
(factory default setting is no delay = instant reaction)*

Example: Delay 30sec. will be selected :

F 

8.6. Number of cycles to send voice & Pager messages

Number of attempts to call each number can be selected in the installer mode (the yellow LED is ON - see 8.1.), entering:

F  **‡**

‡ means number of cycles, can be **1, 2** or **3**. One cycle means sending of the corresponding messages to all stored phone numbers in the **Mem1** to **Mem6** memories
(factory default setting are 3 cycles)

Example: Two cycles will be selected :

F 