


JA-60 "COMFORT" Alarm system Installation manual



Contents:

1.	Before starting	4
2.	Control panel installation	4
2.1.	Opening of the control panel	4
2.2.	Attaching the control panel to the wall	4
2.3.	Antenna installation	4
2.4.	Connection of the AC adapter	4
2.5.	Connection of the telephone line	5
2.6.	Back up battery installation	5
2.7.	Powering of the control panel	5
3.	Installation of detectors	5
3.1.	JA-60N - magnetic door detector installation	5
3.2.	JA-60P - motion detector installation	6
4.	Enrollment of detectors and remote controls	7
4.1.	Procedure for enrolling detectors and controllers	7
4.2.	Enrollment or deletion of a detector or controller to/from a desired position (zone)	7
5.	Testing of detectors and controllers	8
5.1.	JA-60N magnetic door detector testing	8
5.2.	JA-60P motion detector testing	8
5.3.	Remote control and keypad testing	8
5.4.	Recording a detector's location	9
6.	Finishing of the installation	9
6.1.	Specifications	9
7.	Wiring of external devices	10
7.1.	Terminals in the control panel	10
7.2.	Use of external sensors with the JA-60N	11
8.	Control panel programming	11
8.1.	Testing of the system	12
8.2.	Enrollment (teaching) of wireless items	13
8.3.	Exit delay	13
8.4.	Entrance delay	13
8.5.	Alarm duration	13
8.6.	PgX and PgY outputs function	13
8.7.	User recorded message and phone numbers editing in the user mode	14
8.8.	Radio signal jamming testing	14
8.9.	Regular communication checking	14
8.10.	Reset enabled	14
8.11.	Enrollment of the control panel to a UC-216, 222, JA-60K etc.	15
8.12.	No code requested for F1, F2, F3, F4, F8 & F9	15
8.13.	Partial arming with F2 (not split system)	15
8.14.	Siren alarm	15
8.15.	Exit delay audible indication	16
8.16.	Partial arming exit delay audible indication	16
8.17.	Entrance delay audible indication	16
8.18.	Arming and disarming chirp sounds	16
8.19.	Siren alarm in Disarm & Split arming or disarming	16
8.20.	Wireless siren alarm	17
8.21.	Indication of system problems when arming	17
8.22.	Control panel splitting	17
8.23.	Addressing of detectors to sections	17
8.24.	Addressing of the user codes to sections	17
8.25.	Addressing of wireless controllers to sections	18
8.26.	Automatic arming / disarming setting	18
8.27.	Real time and date setting	18
8.28.	New service code setting	19
8.29.	User Mode entering	19
9.	Voice & Pager messages setting	20
9.1.	Telephone numbers entering	20
9.2.	Voice message recording	21
9.3.	Telephone dialer testing	21
9.4.	Dialing method	21
9.5.	Telephone dialer triggering*	22
9.6.	Telephone line checking	22
10.	To enable a remote computer to dial in	23
10.1.	Reaction to an incoming call	23
10.2.	Remote access code setting	23
11.	Factory default RESET	23
12.	Monitoring station communication setting	24
12.1.	Reporting code setting	24
12.2.	Account code setting	25
12.3.	Protocol and Format setting	25
12.4.	Re-dialing pause setting	25
12.5.	Phone number entering	26
12.6.	Digital communicator reset	26
13.	Monitoring station reporting codes table	27
13.1.	Internal structure of Contact ID protocol	28
14.	Personal Computer Interface with JA-60	29
15.	Remote access to the system	29
16.	Recommended Professional installer basic rules	30
17.	Trouble shooting table	30
18.	Possibilities to extend the system	31
18.1	Extension of the system with a subsystem	31
19.	Overview of the JA-60 parts	32

Thank you for purchasing a Jablotron alarm system. Its reliable operation depends on proper installation. We recommend having this alarm professionally installed. To find a qualified installer, please contact your Jablotron Distributor. The manufacturer assumes no liability for damages caused by incorrect installation or improper use of this system.




Fig. 1




Fig.2




Fig. 3 15VAC adapter connection

1. Before starting

First select suitable locations for all sensors and accessories. The location of these sensors should take into consideration the building's safety and basic rules for good radio communication. The working range of the wireless accessories from the control panel is about 100 meters under optimal conditions. However, building materials can absorb or obstruct radio signals, and communication can also be effected by interference from other radio signals. For these reasons, you should anticipate a shorter working range for indoor installations. The control panel checks the radio signals during the installation and if the quality of communication with any accessory is not sufficient, this item will not be enrolled into the system. No part of the system, except the outdoor siren, JA-60A, is suitable for outdoor use.

You can connect your PC to the JA-60 control panel, using the PC-60A connecting cable and the Comlink software (see part 14). This option is convenient for easy programming, diagnostics and storing data about the installation.

2. Control panel installation

The control panel should be easily accessible, but not very visible. There should be a power socket available and also a telephone line (if the system has an optional built in dialer).

Note: Only a qualified technician can provide the installation, telephone line connection and servicing. User is not allowed to open the cover and/or make any modification.

2.1. Opening of the control panel

- Press in the bottom tab via the small slot using a narrow flat screwdriver.
- Remove the cover and gently pull the cable to disconnect it from the board.

2.2. Attaching the control panel to the wall

The surface of the wall should be level. Avoid placing the panel in locations that will result in the antenna being near any large metal objects.

- There are two slots for screws on the back side of the rear panel.
- Drill a hole and insert one of the provided plastic dowels for the top screw.
- Partially tighten the screw, leaving part of its head sticking out.
- Place the rear housing over the screw and slide it down so that the screw is in the middle of the slot.
- Now mark the position of the lower screw through the housing hole and remove the housing. Drill the second hole and insert a second plastic dowel.
- Replace the housing on the top screw once again.
- Do not tighten the lower screw until after the control panel cables are routed (AC adapter, tel. line, additional siren etc. – see description bellow).

2.3. Antenna installation

- Attach the rubber antenna into the hole on the right hand side by the screw on the internal board.
- The AN-01 optional external antenna can be used to improve the radio communication of the control panel. The AN marked connector for the optional antenna is located on the upper end of the control panel board. If the optional external antenna is connected, the rubber antenna must not be used.

2.4. Connection of the AC adapter

- Route the adapter's output cable (15VAC) to the control panel and connect it to the panel's terminals marked AC (see fig. 3.) – arbitrary polarity. **Do not plug the AC adapter into the wall yet.**

Use only adapter SELV

2.5 Connection of the telephone line

(only for models with an optional built in dialer)




Fig.4 TNV-3 telephone line connection

- Use the provided telephone cable to connect the telephone line to the IN jack inside the control panel (see fig. 4),
- Connect any telephone, fax or other phone operated device to the OUT jack, marked with a phone symbol
- When the control panel is in normal stand by mode, the phone line and any attached device will operate as normal.

The dialer can be connected only to a TNV network (Telecommunication Network Voltage)

2.6. Back-up battery installation

WARNING – Do not make any short connection of the battery terminals under any circumstance!

- Straighten and smooth the cables under the control panel and tighten the control panel's screws. (Be sure that the panel is not crooked.)
- Remove the covering folio from the adhesive tape inside the battery compartment (see fig. 5),
- Slide the black wire connector that is inside the battery compartment over the black terminal of the battery (minus),
- Place the battery into the battery compartment so that the Black terminal is inside, and the battery is fixed to the adhesive tape.

- **Do not yet connect the red wire to the Red terminal**

Note: The control panel normally charges the battery. The battery can provide over 12 hours of power to the control panel if there is a failure of the AC power. Before the battery is discharged completely, the control panel will trigger a technical alarm and the battery will be electronically disconnected to avoid any damage. When the AC power is reconnected, the battery will automatically recharge.

2.7. Powering of the control panel

- Connect the Red wire connector over the Red terminal of the battery (positive)
- Reconnect the cable from the front panel to the main board inside the rear housing.
- Reattach the front panel by placing the top side of the front panel over the top of the back panel and then push the bottom side against the wall (the tab will click).
- Plug in the AC adapter to the wall socket.
- The control panel's LED display will display "P", confirming that the system is in the programming mode (for system setting, enrollment of detectors and testing).

Note: if "P" is not displayed at this moment, the control panel is not currently in the factory default setting. Perform Factory default reset. (See section 11).




Fig.5




Fig.6

3. Installation of detectors

Do not install detectors near larger metal objects (this could obstruct radio communication). When choosing the location of the detectors, keep in consideration that a detector's batteries have to be replaced from time to time (approximately once a year). There is a description of the basic installation of the JA-60N (magnetic door detector), and the JA60P (motion detector), below. If you also install other items (smoke detector, gas detector, remote keypad, wireless siren etc.), see manuals provided with each particular item.

3.1. JA-60N - magnetic door detector installation

The JA-60N detects the opening and closing of a door or a window. It also has inputs for external sensors (see section 7.2.). Each detector is equipped with a magnet (movement of the magnet triggers an internal sensor in the detector). We recommend to locate the detector unit on the wall or the frame of the door or window, with the magnet on the moving part of the door or window.




Fig.7

- Open the detector's cover by pressing the internal pawl – see fig. 7
- Install the detector to the desired location using the two provided screws.
- Be sure that the antenna is vertical (pointing up or down)
- Attach the magnet, using the provided screws, to the moving part of the door or window, and attach its cover. The gap between the detector and magnet should not be wider than 5mm when the door is closed (see fig. 8)
- **Warning:** neither the detector nor the magnet should be fixed directly to a metal surface. If there is no other choice, an insulating pad (plastic, wood etc.) 5mm thick or more should be used under the detector and the magnet.

- Use DIP switch no. 1 to select if the reaction of the system to the door opening should be instant or delayed (main entrance door). Switch no. 2 must stay in the OFF position. See fig. 8.
- check that all 3 terminals in the detector are connected together with short connecting loops.
- install other JA-60N magnetic detectors the same way.
- **Be sure to leave all JA-60N detectors uncovered and without batteries installed.**




Fig.8 – detector's mount and reaction setting

3.2. JA-60P - motion detector installation

By using the provided bracket, the JA-60P detector can be installed on the wall or in a corner. The recommended installation height is from 2 to 2.5 meters above the floor. The detector's coverage area is up to 12 meters and it has a detection angle of 120° (see fig. 11). Do not place the detector close to any heating/cooling vents or near any other object that often changes temperature. The JA-60P should not be placed near any item that generates a strong electromagnetic signal (transmitters, electronic regulators etc.). Avoid locations that have intense air circulation.




Fig. 9

- A. Attach the bracket with the two provided screws, being sure that the arrow inside the bracket is pointing up. We recommend to install one screw in the pre-punched hole on the lever of the tampering sensor (see fig. 9. A). The second hole can be easily punched out from the pre-formed holes. Tighten the screws firmly, being sure that the bracket is not crooked.
- B. Click on the complete detector (including cover). Both tabs must click. Check that the detector is firmly fixed.
- C. Open the cover of the detector (press in on both sides 1/3rd from the top)
- D. Select Instant or Delayed reaction of the system to the detector's triggering by using DIP SW 2 (see fig. 10)
- E. Install other JA-60P motion detectors the same way, leaving them all **uncovered and without batteries**




Fig.10

4. Enrollment of detectors and remote controls

At this moment, all detectors (and wireless keypads - if used) should be installed, without covers and without power (batteries). The control panel should be in the programming mode, displaying „P“ (see part 2.7.). As a maximum, 16 detectors and 8 remote controls (including wireless keypads) can be used with the control panel. One JA-60A, wireless outdoor siren, can be enrolled as well. An additional JA-60 control panel can be enrolled as a subsystem (see part 18.1.). A wire operated keypad, JA-60E, can be simply plugged into the control panel's data connector.

4.1. Procedure for enrolling detectors and controllers:

- a) The control panel must display „P“ (programming mode – see 2.7).
- b) Press key **1** to enter the enrolling mode.
- c) A free detector position number (1 to 16) will be displayed, showing that the control panel is ready to accept an enrollment signal from a detector.
- d) Install the two provided batteries into a detector and leave it uncovered.
- e) The detector will generate an enrollment signal, and the control panel will „beep“ to indicate reception of the signal (press F to select a louder „beep“ sound) and the LED display will display the number of the next free position.
- f) Step by step, install batteries into all of the installed detectors and wireless keypads (if used).
- g) To enroll an RC-11 remote control (or RC-22 panic button), press and hold both its buttons for 3 seconds. The controllers and keypads are enrolled to special positions which are displayed as **c1** to **c8** on the LED display (the system automatically recognizes and differentiates the controllers from detectors)
- h) To exit the enrolling mode, press the **N** key (a „P“ will again be displayed on the LED display)

Note: if an item was not enrolled after its batteries were installed, it is because the control panel recognized its radio signal as a weak one. Items are only enrolled if their radio signal has a level which guarantees reliable communication. Check the detector's batteries and try to enroll the problematic sensor once more. If it is not accepted by the control panel, you should change the location of the item. All items should be located 1 m or more from the control panel.

4.2. Enrollment or deletion of a detector or controller to/from a desired position (zone)

The control panel offers the next free position automatically in the enrolling mode. It is also possible to select a desired position manually and to change the position of an enrolled item or to delete it. The procedure is similar to the one in part 4.1:

- Press key **1** to enter the enrolling mode; a free position is displayed.
- **Use key 1 and 6 to scroll** (up and down) all control panel positions – 1 to 16 (detectors) – c1 to c8 (controllers & keypads) – A (wireless siren) – J (sub control panel JA-60). The LED display shows the position number while the Battery LED indicates if the position is occupied (if the Battery LED is illuminated, it indicates that the position is occupied).
- Detectors and keypads are automatically enrolled when their batteries are installed. A remote control is enrolled only after both of its buttons are simultaneously pressed and held for 3 seconds.

Note: The control panel will not allow you to enroll a detector as a controller, and vice versa (if you try to, the next suitable position will be used automatically).

To change the position of an enrolled item is simple. **Enroll it to the new selected position** (the item will „move“). If you enroll an item to an occupied position, the former item will be deleted and the new enrollment is valid. Only one item (detector, controller etc.) can be stored to each position.

Erase an enrolled item the following way: in the enrolling mode **select** the corresponding **position** and then **press and hold key 2**. If you press and hold key 3, all enrolled controllers (remote controls and keypads) will be erased. Pressing and holding key 4 will erase all enrolled items (detectors, controllers, siren and the sub system). A long beep will acknowledge successful erasing.

5. Testing of detectors and controllers

The control panel should be in the programming mode for testing – (LED display will show „P“) (see part 8. how to enter programming mode). If the control panel will not indicate a detector's triggering during testing, it means that this detector was not enrolled (see note in part 4.1.).

5.1. JA-60N magnetic door detector testing

- Attach the detector's cover (the detector will automatically enter a testing mode for 5 minutes)
- Opening and closing of the door/window will be confirmed by the detector's LED.
- The control panel's LED display will display the triggered detector's number and it will make a beep - press F to select the loudness of the beep (0-I-II).
- 5 minutes after the cover was attached, the detector will enter its normal mode and its LED indicator will be switched off (battery energy saving function). Open and close the detector's cover to reset the testing mode for an additional 5 minutes, if needed.

5.2. JA-60P motion detector testing

- Attach the detector's cover and wait until the LED turns off. From this moment the detector will be in its testing mode for 5 minutes and each detected movement will be confirmed by the detector's LED.
- The control panel's LED display will display the triggered detector's number and it will make a beep - press F to select the loudness of the beep (0-I-II).
- Confirm that the detector covers the protected area as you expected (see diagram in fig. 11). If you need another coverage pattern (long corridor, pet zone), you can get an optional detector lens from your distributor.
- 5 minutes after the cover was attached, the detector will enter its normal mode and its LED indicator will be switched off (battery energy saving function). Open and close the detector's cover to reset the testing mode for an additional 5 minutes if needed.




fig. 11

Note: the motion detector, in normal operating mode, conserves battery energy. It will not indicate triggering with its LED. It will also **block the movement sensor for a period of 5 minutes** after a movement is detected. This means that when users are in the protected area and they move frequently in front of the detector, it will transmit information about the movement to the control panel only once every 5 minutes. But when the users leave the area, the detector will be ready for instant detection 5 minutes after the last triggering. This system significantly prolongs the life time of the batteries.

To change the period, for which the sensor is blocked after triggering from 5 min. to 1 min., press and hold the detector's tamper switch when you install the batteries into it. This mode is suitable when you prefer more frequent transmissions of the signal. However, the life time of the batteries will usually be shorter, depending on how frequently the detector is triggered.




Fig.12

5.3. Remote control and keypad testing

- Press any button on the remote control (panic button) or enter a valid code on the wireless keypad (1234 factory default setting)
- The control panel's LED display will display the controller's number (c1 to c8) and it will beep - press F to select the loudness of the beep (0-I-II).
- This procedure allows you to test the remote control's working range
- The wire operated keypad, JA-60E, has identical functions as the control panel's keypad.

5.4. Recording a detector's location

After successfully testing all detectors, we recommend that you record the location of the sensors directly on the control panel (area under the LED display). A suitable marker for this is provided. If you need to erase your record, use a tissue dipped in rubbing alcohol.

You can also record the location of the detectors on the user instruction card, and in the Comlink software as well. (See software instructions)




Fig. 13

6. Finishing of the installation

- Check that all detectors and other items have their covers attached.
- If the control panel has a built in telephone dialer, record your voice message and program the desired telephone numbers (see part 9).
- We recommend to set the date and time in the control panel (see part 8.21.); The control panel stores all events to an events list in its internal memory, including the date and time of the event. The details from the memory can be viewed any time in the future via a connected PC and Comlink software. The PC can also be used for convenient setting of the control panel.
- The system has a factory default setting, which allows you to use it without any other additional programming. If you want to customize the control panel setting, see part 8.
- Change the system Service Code to protect against unauthorized access to the programming mode (see part 8).
- **Exit the programming** mode by pressing the **N** key. The control panel will then enter the disarm mode. See the user instruction card for information on how to operate the system.
- If you have troubles with your system, see the Trouble shooting table in part 17.

Note: during testing and normal operation you should be aware of the following function: if four alarms are triggered from the same detector during the arming period, the detector will be bypassed automatically for the rest of the arming period. This feature prevents unlimited number of alarms (and possible conflict with your neighbors!) when for example improperly closed doors inside the house are repeatedly moved by the wind. Such a bypass of problematic detector is reset with the disarming of the system.

This is the end of the basic installation procedure.

6.1. Specifications:

control panel power	15V~, 0.2A, 50Hz (adapter SELV)
back up battery	12V, 1,3Ah
back up power output	13.8V, max. 50mA (permanent load), max. 1A (10 minutes)
number of zones (detectors)	16
number of controllers	max. 8
events memory	127 latest events incl. date and time information
built in siren	116dB
working frequency	433.92 MHz (optional)
RF approved according	EN 300 220
complies with	EN 50131-1, 50131-6
telephone dialer*	voice message to 4 numbers numeric message to a Pager digital communication to a monitoring station
approved according*	TBR21
electrical safety and EMC	EN 41003 (EN 60065), ETS 360683
working environment	indoor use, -10 to +40°C

* only for control panels equipped with the telephone dialer module



Notes for JA-60X dialer use in European countries:
Equipment is listed under the name of product: **Wireless alarm system JA-60 "Comfort"**
Equipment is designed to work with networks according to TBR 21 and tested according to EG 201 121 V1.1.3, Jan. 2000 including Advisory Notes for following countries: **Germany, Norway, Switzerland**
Equipment was not tested according to advisory additional notes for: **Greece, Portugal and Spain**
Equipment may have interworking difficulties with the local networks requiring current limitation as in **France**
Italy's legislation requires that use of SDR is subject to license.

* can be connected to analogue interfaces TBR 21/1998, EG 201 121 V1.13/2000, AS/ACIF S002/2001 (Australia)

Hereby, Jablotron Ltd., declares that this JA-60 is in compliance with the essential requirements and other relevant provisions of Directive 1999/5/EC. Original of the conformity assessment can be found at the web page www.jablotron.cz, section Technical support.

Note: Dispose of batteries safely depending on the type of the batteries and local regulation. Although this product does not contain any harmful materials we suggest you to return the product to the dealer or directly to the producer after usage.

7. Wiring of external devices

In addition to using wireless items, which are part of the JA-60 system, hard wired devices can be wired to the system. The JA-60 control panel (JA-60K) and the JA-60N detector are both equipped with terminals for wiring.

7.1. Terminals in the control panel

There are terminals in the JA-60K for use when wiring in external devices:

- TMP** terminals used for connecting a tamper switch of an external device. This input must be equipped with end of line 2.2 kOhm resistor. If the line resistance changes in $\pm 30\%$ or more, the control panel concludes that the tamper is broken.
- PGX** is an output (opened collector of a switching transistor to GND, max. 12V, 100mA). The function of this output is determined by the setting of parameter 23x in the programming mode (see 8.6). The control panel also wirelessly transmits the PGX signal and unit UC-216 can be used as a remote output of this signal (see 19.).
- PGY** is an output (opened collector of a switching transistor to GND, max. 12V, 100mA). The function of this output is determined by the setting of parameter 24x in the programming mode (see 8.6). The control panel also wirelessly transmits the PGY signal and unit UC-216 can be used as a remote output of this signal (see 19.).
- C** is a common contact of the alarm output relay, max. load 60V / 1A,. The relay is turned on during any alarm of the control panel.
- NC** is a normally closed contact of the alarm output relay.
- NO** is a normally open contact of the alarm output relay.
- GND** is a common ground terminal of the power output (-).
- SIR** is an external siren output. In the normal mode, it has a +U voltage. In the alarm mode it has a GND potential. Connect an ordinary external siren to +U and SIR terminals (max. load 1A). A back up siren charging input should be connected to the GND and the SIR terminals (during an alarm, the charging will temporarily halt).
- +U** is a back up +13.8V power output. The permanent load should not be higher than 50mA. A short time consumption from this output can be up to 1A (max. 10 minutes). This output is fused and supervised by the control panel. If it is overloaded, a control panel failure will be indicated (fault C).
- AC** a pair of terminals to connect the AC adapter DE-12-15 cable (15 VAC) – arbitrary polarity
- 1234** four small sized terminals of the digital bus – to wire JA-60E keypad when used (the same number terminals in the control panel and in the keypad should be connected)




Fig.14

7.2. Use of external sensors with the JA-60N




Fig.15

The JA-60N detector can be used to wire external sensors which have contacts on their outputs. For example, it can be used to protect multiple doors or windows (see fig. 16). The built in magnetic sensor of the JA-60N can also be disabled (DIP switch number 2 to position ON) and then the JA-60N works only as an interface for external sensors. Two input loops (TAMP & INP terminals) are activated when disconnected from the GND terminal.

INP – when this input is triggered (disconnected from GND), the JA-60N will send the same information as if the built in magnetic sensor was triggered. Reaction of the system can be selected with DIP switch number 1 (ON= instant or 1= delayed).

TAMP – when this input is triggered (disconnected from GND), the unit will send the same information as if the built in tamper sensor was triggered.

Balanced loops – the inputs INP & TAMP can also work as balanced loop inputs for higher security of connected cables. If you install an End Of Line resistor 10k in the end of the loop (INP or TAMP), the JA-60N will automatically recognize this situation and from this moment it will react to any change of the resistance (changes $\pm 30\%$ or more will trigger the input).

Note: if either the INP or TAMP terminal is not used, it must be connected to the GND terminal. The procedure to enroll the JA-60N with external sensors is identical as described in section 4.1. If you change the DIP switch's setting, the system will accept the new setting after the detector's cover is closed.




Fig.16

8. Control panel programming

Functions of the system can be customized. The most convenient programming method is via a connected PC using the Comlink software (see 14). Programming can also be performed by entering programming sequences from the system keypad while in the programming mode:

- Enter the programming mode (entering **F 0 SC** - SC = Service Code, factory default SC=6060), indicated by a „P“ on the display. This can only be done while the panel is disarmed. In this mode no alarm can be triggered. Detectors and other accessories can be enrolled, the system parameters can be set up and the system can be tested.
- The parameters of the control panel can be set by entering programming sequences from the keypad. Any unfinished programming sequence can be terminated by pressing the **N** key.
- **To exit the programming mode, press the N** key („P“ will turn off). If any fault is indicated when you try to exit the programming mode, the control panel will inform you about the problem (see programming sequence 39x for more details).

List of control panel programmable parameters

Function	sequence	options	factory d.	note
Enrolling of detectors and controllers	1	1 & 6 scrolling, hold 2 to erase position, 3 all controllers, 4 to erase all items	-	
Exit delay	20x	x = 1 to 9 (x 10sec.)	30sec.	
Entrance delay	21x	x = 1 to 9 (x 10sec.)	30sec.	
Alarm duration	22x	x = 1 to 8 (min.), for x=0 it will be 10 sec., for x=9 15min.	4min.	
Function of PgX output	23x	x = 0 to 8 (0-Chime, 1-Fire, 2-Arm, 3-Panic, 4-Alarm, 5-Door, 6-Home, 7-NO AC, 8-Phone)	Chime	
Function of PgY output	24x	x = 0 to 8 (0-Chime, 1-Fire, 2-Arm, 3-Panic, 4-Alarm, 5-Door, 6-Home, 7-NO AC, 8-Phone)	Arm	
Voice message & phone numbers: editable in the user mode	25x	251 = YES 250 = NO	NO	
Radio signal jamming regular testing	26x	261 = YES 260 = NO	NO	
Regular communication check enabled	27x	271 = YES 270 = NO	NO	
RESET enabled	28x	281 = YES 280 = NO	YES	
Control panel teaching to a UC-2xx, subsystem,...	299	will send enrolling signal	-	
No code requested (effects F1, F2, F3, F4, F8 & F9)	30x	301 = YES 300 = NO	YES	
Partial (Home) arming enabled (F2)	31x	311 = YES 310 = NO	YES	
Siren alarm enabled	32x	321 = YES 320 = NO	YES	
Exit delay audible indication enabled	33x	331 = YES 330 = NO	YES	
Partial arming exit delay audible indication	34x	341 = YES 340 = NO	NO	
Entrance delay audible indication enabled	35x	351 = YES 350 = NO	YES	
Arming & disarming chirp sound enabled	36x	361 = YES 360 = NO	NO	
Siren in Disarm & Partial arming enabled	37x	371 = YES 370 = NO	YES	
Wireless siren alarm enabled	38x	381 = YES 380 = NO	YES	
Indication of system problems when arming	39x	391 = YES 390 = NO	NO	
Split control panel (A, B & C sections)	690x	6901 = YES 6900 = NO	NO	
Addressing of wireless detectors to sections	61 nns	nn- zone n., s- section	1-10 A	only when split
Addressing of user codes to sections	62 nns	nn- code n., s- section	all A	only when split
Addressing of wireless controllers to sections	63 nns	nn- controller n., s- section	all A	only when split
Automatic arming/disarming setting	64nahhm m	n- 0-9, a-action #, hh-hours, mm-min.	all off	
New Service Code setting	5 nSC nSC	nSC = new Service Code (must be entered twice)	6060	
User Mode entering	6999	Switching to the User mode	-	
Real time and date setting	4 hh mm DD MM YY	00 00 01 01 00		

8.1. Testing of the system

when the LED display displays „P“

In the programming mode (indicated by a „P“) no alarm can be triggered. The control panel will confirm receiving any signal from an enrolled detector or another JA-60 wireless item. It will make a beep - press F to select the loudness of the beep (0-I-II) and the LED display will show which signal was received. Some detectors (JA-60P, JA-60N etc.) have an extra testing mode, which is usually activated for 5 minutes after the detector's cover is attached (see manuals of the particular detectors).

Just as in the programming mode, the signals from all enrolled items are confirmed in the user mode (confirmed by a „U“). The user mode is accessible with the Master code and the supervisor of the system can use this mode to replace batteries in items or for system testing. To open the user mode enter F 0 MC (= Master Code) when the control panel is disarmed.

8.2. Enrollment (teaching) of wireless items

enter: 1

As a maximum 16 detectors and 8 controllers (remote controls & keypads) can be enrolled to the control panel. A wireless siren and an additional JA-6x control panel (subsystem) can be enrolled as well.

- **press key 1** (while „P“ is displayed) to enter the enrolling mode. The control panel will display the next free position to enroll a detector.
- **Use key 1 and 6 to scroll** (up and down) all control panel positions – 1 to 16 (detectors) – c1 to c8 (controllers & keypads) – A (wireless siren) – J (sub control panel JA-60, 65). The display shows the position number while the Battery LED indicates if the position is occupied (If the Battery LED is illuminated, it indicates that position is occupied).
- Detectors and keypads are automatically enrolled when their power is switched on (batteries are installed). A remote control is enrolled only after both of its buttons are simultaneously pressed and held for 3 seconds. A subsystem control panel will enroll after sequence 299 is entered while it is in its programming mode. The system will not allow enrollment of an item into a non-corresponding position (a detector can not be enrolled into a controller position etc.). If you try to enroll an item into an incorrect position, the control panel will automatically select a suitable position.
- **Control panel confirms enrollment** with a „beep“ (press F to select a louder “beep” sound). The LED display will show the number of the enrolled item for 2 seconds and then it will display the number of the next free position.
- **To change the position** of an enrolled item is simple. **Enroll it to the new selected position** (the item will „move“). If you enroll an item to an occupied position, the former item will be deleted and only the new enrollment is valid. Only one item (detector, controller etc.) can be stored to each position.
- **Erase an enrolled item** the following way: in the enrolling mode select the corresponding position and then press and hold key 2 for two seconds. The item will be erased (confirmed with a long beep). If you press and hold key 3, all enrolled controllers (remote controls and keypads) will be erased. Pressing and holding key 4 will erase all enrolled items (detectors, controllers, siren and the sub system).
- **The JA-60A wireless siren will generate an enrollment signal** when its power is switched on (it will enroll to position A). If you need to enroll a siren which is already powered and it is not possible to easily switch off its power, you can enroll it the following way: enter the enrolling mode and then enter the 6 digit siren production code (printed in the siren’s manual). The control panel will “request” the siren to send its enrollment signal. The siren will send the signal only if it has no current communication with any other control panel (This protects you from enrolling your neighbor’s siren). Enrollment is completed about five seconds after the code is entered.

Note: *if an item was not enrolled after its batteries were installed, it is because the control panel recognized its radio signal as a weak one. Items are only enrolled if their radio signal has a level which guarantees reliable communication. Check the detector’s batteries and try to enroll the problematic sensor once more. If it is not accepted by the control panel, you should change the location of the item. All items should be located 1 m or more from the control panel.*

8.3. Exit delay

sequence: 2 0 x

To change the duration of the exit delay enter

20x (where **x** represents time in seconds x10). The delay can be selected from 10 to 90 seconds.

Example: to select an Exit delay duration of 20 seconds, enter 202

Factory default setting is 30 seconds

8.4. Entrance delay

sequence: 2 1 x

To change duration of the entrance delay enter:

21x (where **x** represents time in seconds x10). The delay can be selected from 10 to 90 seconds.

Example: To select entrance delay duration of 40 seconds, enter 214

Factory default setting: 30 seconds

8.5. Alarm duration

sequence: 2 2 x

The alarm duration can be selected from 1 to 8 or 15 minutes (or 10 seconds) entering **22x** (where **x** represents time in minutes, for x=0 the duration will be 10 seconds, for x=9 the duration will be 15 minutes).

Example: to select an alarm duration of 5 minutes, enter 225

Factory default setting is 4 minutes

8.6. PgX and PgY outputs function

sequences: 2 3 x & 2 4 x

The control panel outputs PgX and PgY can have different functions, depending on parameter **x** in the corresponding sequence:

2 3 x – determines triggering of **PgX**

2 4 x – determines triggering of **PgY**

where **x** represents the following functions (non split system):

- 0 Chime** – triggered during the entrance delay (pre-alarm output)
- 1 Fire** – triggered by a fire alarm (by a smoke or a gas detector)
- 2 Arm** – activated when the control panel is armed (complete & partial arming)
- 3 Panic** – activated when a silent panic alarm is triggered
- 4 Alarm** – triggered by any audible alarm (except panic alarm)
- 5 Door** – activated for 5sec. after F3 entering (electric door lock opening)
- 6 Home** – activated when the control panel is partially armed (Home arming)
- 7 No AC** – triggered by an AC power failure
- 8 Phone** – output can be operated remotely by phone or by SMS (if this feature is supported by installed communicator) or locally from the keypad by F81 (ON) and F80 (OFF).

Table for split system:

x	23x (PgX)	24x (PgY)
0	Alarm A	Alarm A
1	Alarm B	Alarm B
2	Chime A	Chime A
3	Chime B	Chime B
4	Arm A	Arm B
5	Door A	Door B
6	Panic A	Panic B
7	FIRE	NoAC
8	Phone	Phone

Example for non split system: the PgX will work as a Panic output when 233 is entered, PgY as Door output when 245 is entered.

Factory default setting: PgX=Chime, PgY=Arm

Note: the control panel also wirelessly transmits the PgX and PgY signals. Wireless output modules UC-216 and UC-222 can be used to receive the signals. The function of the UC module output relays is determined by the 23x and 24x setting.

8.7. User recorded message and phone numbers editing in the user mode *sequence: 2 5 x*

The User mode, which is accessible with F 0 “Master Code”, is for battery replacement and system testing. This setting enables the user to change the voice message and telephone numbers of the built in dialer. If the changes are enabled, then programming sequences 7=tel. numbers programming, 8=voice message recording and 89=dialer testing are accessible in the User mode (see description from 9.1. to 9.3.).

options:

- 2 5 1** changes **enabled**
- 2 5 0** changes **disabled** (no programming in the User mode)

Factory default setting: changes disabled

8.8. Radio signal jamming testing *sequence: 2 6 x*

When this function is enabled, the control panel will indicate trouble if the working band is jammed for more than 30 seconds. Jamming will trigger an alarm when the control panel is armed.

options:

- 2 6 1** testing **enabled**
- 2 6 0** testing **disabled**

Factory default setting: disabled

Note: in some locations the system can be repeatedly jammed for some period of time (near radar, TV station etc.). In these cases the JA-60 system can work without any problems because all important data is repeated, but the jamming test should not be enabled. The level of the signals and interference can be observed using the Comlink software (see 14.)

8.9. Regular communication checking *sequence: 2 7 x*

The control panel will check communication regularly with all enrolled items (detectors, keypads, siren etc.) when this function is enabled. If communication is lost with any item, the control panel will indicate the fault of this item (when armed it will also trigger an alarm).

options:

- 2 7 1** checking **enabled**
- 2 7 0** checking **disabled**

Factory default setting: checking disabled

Note: in some locations with a strong radio interference (near radar, TV station etc.) the communication can be jammed periodically. The control panel can detect such a strong interference as a temporary loss of communication with an item. Even in this case, the JA-60 system is usually able to work without any problems, because all important data is repeated, but the communication check should not be used.

8.10. Reset enabled *sequence: 2 8 x*

The factory default reset (see 11.) can be disabled. This way no unauthorized future programming of the control panel will be possible.

options:

2 8 1 reset **enabled**

2 8 0 reset **disabled**

Factory default setting: reset enabled

Note: if the Master or Service code is forgotten when the reset is disabled, the reset of the control panel will be possible only by the manufacturer.

8.11. Enrollment of the control panel to a UC-216, 222, JA-60K etc. *sequence: 2 9 9*

The control panel can send wireless data to output modules UC-216, UC-222 and UC-260 (see 19.) It can also work as a subsystem of another JA-60 or JA-65 control panel.

Enter the enrolling mode of the **UC receiving device** and then enter **299** and the control panel will generate the enrollment signal.

If you want to enroll a **subsystem** to your control panel, enter the enrolling mode on the MASTER control panel (8.2.) and then enter sequence 299 in the programming mode of the sub control panel.

8.12 No code requested for F1, F2, F3, F4, F8 & F9 *sequence: 3 0 x*

If this parameter is enabled, no code is requested for functions F1, F2, F3, F4, F8 and F9. When this parameter is disabled, these functions can be used only when followed by a code (Master or User) – see the following table:

function / setting	300	301
arming	„code“	F 1
partial arming	F 2 „code“	F 2
door opening	F 3 „code“	F 3
memory reading	F 4 „code“	F 4
appliance control	F 8 „code“ 0 F 8 „code“ 1	F 80 F 81
message listening	F 9 „code“	F 9

„code“ = Master or User

Factory default setting: no code requested

Note: this feature is also selectable on the JA-60D wireless keypad and it is independent from the control panel setting.

8.13. Partial arming with F2 (not split system) *sequence: 3 1 x*

In partial arming, the control panel reacts only to detectors addressed to section A (see 8.22) and it ignores the triggering of detectors in section B or C (except smoke and gas detectors). Partial arming can be disabled with this sequence.

options:

3 1 1 partial arming **enabled**

3 1 0 partial arming **disabled**

Factory default setting: partial arming enabled

8.14. Siren alarm *sequence: 3 2 x*

The built in siren is active when any alarm is triggered (except silent Panic alarm). The alarm indication can be disabled with this parameter.

options:

3 2 1 siren **enabled**

3 2 0 siren **disabled**

Factory default setting: siren enabled

8.15. Exit delay audible indication

sequence: 3 3 x

The exit delay can be indicated by the „beeping“ of the control panel (for the last five seconds, the beeping is faster). The audible indication can be disabled with this setting.

options:

3 3 1 indication **enabled**

3 3 0 indication **disabled**

Factory default setting: indication enabled

8.16. Partial arming exit delay audible indication

sequence: 3 4 x

Partial arming with F2 provides an exit delay for delayed reaction detectors in positions 1 to 10. The exit delay for partial (split) arming can be indicated by the „beeping“ of the control panel (for the last five seconds the beeping is faster).

options:

3 4 1 indication **enabled**

3 4 0 indication **disabled**

Factory default setting: indication disabled

Note: when this indication is disabled, the confirmation of partial arming and disarming will automatically be silent, regardless of the 36x setting.

8.17. Entrance delay audible indication

sequence: 3 5 x

The entrance delay can be indicated by a rapid „beeping“ of the control panel. This indication can be disabled with this setting.

options:

3 5 1 indication **enabled**

3 5 0 indication **disabled**

Factory default setting: indication enabled

8.18. Arming and disarming chirp sounds

sequence: 3 6 x

The control panel confirms arming with a beep and disarming with two beeps (3 beeps after disarming indicates user information on the LED display). 4 beeps indicates that a bypass is activated or a component is not ready. These sounds can also be generated more loudly with the built in siren.

options:

3 6 1 siren chirps **enabled**

3 6 0 siren chirps **disabled**

Factory default setting: siren chirps disabled

Note: setting of chirp sounds is valid even if the siren is disabled for alarms with parameter 320. Partial (split) arming is always silent, if sequence 340 is selected. Chirp sounds can also be generated with the JA-60A wireless siren (self-contained setting in the wireless siren).

8.19. Siren alarm in Disarm & Split arming or disarming

sequence: 3 7 x

The built in siren can be disabled for alarms during the Disarm or Partial & Split control panel arming (while somebody is indoors). If the in siren is completely disabled for alarms with parameter 320, this setting is moot.

options:

3 7 1 alarm **enabled**

3 7 0 alarm **disabled**

Factory default setting: enabled

8.20. Wireless siren alarm

sequence: 3 8 x

The wireless siren alarm function can be disabled with this parameter. This setting will have no influence on the outdoor siren chirp sounds function if enabled in the siren.

options:

3 8 1 siren **enabled**

3 8 0 siren **disabled**

Factory default setting: siren enabled

8.21. Indication of system problems when arming

sequence: 3 9 x

The system regularly checks the conditions of all items (detectors, keypads etc.). This setting ensures that the user will be warned with 4 rapid beeps after arming, if any component of the system is not ready for arming. Cause of the problem (for example permanently triggered detector, lost communication etc.) will remain displayed on the control panel. If the user ignores this warning, the system will arm after the exit delay, then an alarm will be triggered and finally the problematic item will be bypassed for this arming period. After disarming in such a mode, three beeps will be generated as well.

When the indication is not selected, the problematic item will be bypassed when arming with neither warning nor alarm.

If a permanently activated detector is deactivated during arming (for example your main door is not closed), the bypass of this detector will be canceled automatically and the detector will be ready to trigger an alarm after it is activated (if you close the door after the system is armed).

options:

3 9 1 warning **enabled**

3 9 0 warning **disabled**

Factory default setting: warning disabled

8.22. Control panel splitting

sequence: 690 x

The control panel can be split in to 2 independent sections A and B, with a shared common area C. This way the system can be operated by two independent user groups. In fact the system in this mode works like two independent systems. If the system is split to the sections with this setting, it is possible to address detectors, user codes and remote controls to the above sections (see. 8.22, 23 and 24.).

options:

6 9 0 0 **no splitting** (partial arming available in this mode)

6 9 0 1 **splitting to sections A, B and common C** (C is armed only when both A and B are armed)

Factory default setting: no splitting

8.23. Addressing of detectors to sections

sequence: 61 nns

If the control panel is split (see 8.21.), the detectors can be addressed to sections by entering:

61 nns

where: **nn** = wireless detector zone number: from 01 to 16

s = section: 1 = A, 2 = B, 3 = C (common section - it is armed only when both A and B are armed). If the control panel is not split, and s=2 (or s=3) is selected, this detector will be bypassed while partial arming.

Example: to address detector zone number 3 to section A enter: 61 031

Factory default setting: detectors 1 - 10 are addressed to A, detectors 11 - 16 are addressed to B

8.24. Addressing of the user codes to sections

sequence: 62 nns

If the control panel is split (see 8.21.), the user codes can be addressed to sections A or B by entering:

62 nns

where: **nn** = user code number: from 01 to 14

s =section: 1 = A, 2 = B

Notes:

- If the control panel is not split, this setting has no effect.
- Master code (MC) can not be addressed. If the system is split, the use of MC will arm all sections if no section is armed or it will disarm all sections if any is armed. If no code arming is not used (sequence 300) and the system is split then entering F1 MC will effect only section A and entering F2 MC will effect only section B.

Example: to address user code number 4 to section A enter: 62 04 1

Factory default setting: all user codes (01 - 14) are addressed to section A

8.25. Addressing of wireless controllers to sections **sequence: 63 nns**

If the control panel is split (see 8.21.), the wireless controllers (RC-11, RC-22 and JA-60D) can be addressed to A or B section by entering:

63 nns

where: **nn** = number of the enrolled controller from 01 to 08 (c1 to c8)
s = section: 1 = A, 2 = B

Notes:

- If the control panel is not split, this setting has no effect
- For the JA-60F keypad this setting has no effect (its user codes are determined by 62nns setting)

Example: to address controller number 5 to section A enter: 63 051

Factory default setting: all wireless controllers are addressed to section A

8.26. Automatic arming / disarming setting **sequence: 64 nahhmm**

The control panel can automatically arm and disarm for a requested period of a day. Up to ten instructions (time & action) can be programmed in the period of one day by entering:

64 nahhmm

where: **n** = instruction number from 0 to 9
a = action (see the actions' table)
hh = hours (from 00 to 23)
mm = minutes (from 00 to 59)

actions' table

a	no splitting	split system
0	no action	no action
1	arm all	arm all
2	disarm	disarm all
3	partial arming	arm A
4	partial arming	arm B
5	disarm	disarm A
6	disarm	disarm B

Notes:

- If any automatic action is selected, it will be performed everyday in the programmed time, following the internal control panel clock (see 8.26.).
- The automatic arming and disarming can be overridden manually anytime (by an user code or a remote control)
- If the control panel is in the requested arming mode before the action time, performance of the programmed action will not change the arming

Example: to program an automatic complete arming of the system at 21:15 everyday enter: 64 0 1 21 15

Factory default setting: all instructions are set for no action

8.27. Real time and date setting **sequence: 4 hh mm dd MM YY**

The control panel has a built in real time clock. All events are stored to the event memory including the time of the event. The clock should be set after the installation is complete.

Time Setting:

4 hh mm dd MM YY

where **hh** = hours (24 hr. cycle)
mm = minutes
dd = day
MM = month
RR = year

Example: on Jun. 30 2005 at 17:15 enter: 4 17 15 30 06 05

After the control panel is powered, its internal clock's default setting is: 00 00 01 01 00

Note: detail control panel event history can be viewed with a connected PC using Comlink software.

8.28. New service code setting

sequence: **5 nSC nSC**

The Service Code can be used to enter the programming mode. A new Service Code must be entered twice in the sequence to avoid an error.

To change the code enter:

5 nSC nSC

where nSC is your new Service Code (four digits)

Example: to change service code to 1276 enter: 5 1276 1276

Factory default setting: service code is 6060

8.29. User Mode entering

Sequence: **6 9 9 9**

This sequence is used to switch from the Service Mode to the User Mode, where you can set zones' bypass (see User's manual). You can exit the User Mode by pressing the "N" button. The bypassed zones will remain active after the leaving the User Mode.

9. Voice & Pager messages setting

A control panel equipped with a telephone dialer can automatically send a voice message(s) and a code to a Pager. The most convenient programming of the dialer is via a connected PC using the Comlink software (see 14). Programming can also be performed by entering programming sequences from the system keypad while in the control panel programming mode:

- Enter the programming mode (entering **F 0 SC** - SC = Service Code, factory default SC=6060), indicated by a „P“ on the display. This can only be done while the panel is disarmed.
- The parameters of the dialer can be set by entering programming sequences from the keypad. Any unfinished programming sequence can be terminated by pressing the **N** key.
- **To exit the programming mode, press the N** key („P“ will turn off). If any fault is indicated when you try to exit the programming mode, the control panel will inform you about the problem (see 8.20.).
- Telephone numbers and the voice message can also be set up in the User Mode when enabled (see 8.6.2.)

List of the voice & Pager programmable parameters

Function	sequence	options	factory d.	note
Dialing method	90x	901 = tone 900 = pulse	tone	
Triggering of the dialer with a Panic alarm	91x	911 = YES 910 = NO	911	
Triggering of the dialer with an Intruder alarm	92x	921 = YES 920 = NO	921	
Triggering of the dialer with a Fire alarm	93x	931 = YES 930 = NO	931	
Triggering of the dialer with a Tamper alarm	94x	941 = YES 940 = NO	941	
Triggering of the dialer with a Technical alarm	95x	951 = YES 950 = NO	951	
Telephone line checking enabled	99x	991 = YES 990 = NO	NO	
Store telephone numbers for voice message	7xx..x F y	xx...x = tel. number, y = memory 1 to 4, pause = F0	1: 2: 3: 4: 5:	
Pager dialing programming	7x.xF9z..zF5	x..x = provider tel. number z..z = pager number + message		
Erase telephone number	7F0Fy	y = memory 1 to 5, entering 7F0F0 erases all		
Record voice message	8 0 (hold 0 and talk to control panel)		2 messages - see 9.2.	

9.1. Telephone numbers entering

sequence: **7xxx....xxFy**

Store telephone numbers for voice message entering:

7 xx... xx F y

where xx...xx = telephone number
y = memory number from 1 to 4

A telephone number can have a maximum of 16 digits. A **pause** can be entered with **F0** (pause can not be entered as the first digit).

Example: to store tel. number 483 123456 to memory no. 2 enter: 7 483 F0 123456 F2

Note: enter a pause (F0) after the last digit of a number which is calling a mobile phone. This way the number will be called only once and the dialer will not check the line signals (some mobile phone systems do not generate standard telephone line signals).

When activated, the dialer will disengage all other devices hooked up to the phone line (telephone, fax..). It will then, one by one, call and play the user recorded message, for all programmed numbers. If the dialer makes a successful connection to a programmed number, it will not call that number again. If the number is busy, the dialer will make 3 more attempts to call it.

Empty tel. number memories are skipped. If all memories are empty, the dialer is completely disabled.

To delete a telephone number enter:

7 F0 Fy

where **y** is a memory number from 1 to 4

entering **7 F0 F0** will erase all tel. numbers, including the Pager number

Store number to call Pager (to memory number 5) entering:

7 xx..x F9 zzz....zz F5

where **xx...x** = provider prefix

F9 = separator (it will wait for a provider's signal and will switch to DTMF if not used)

zzz...zz = pager number and numeric message and other specific codes (language selectors, end of message etc.) if requested by the Paging provider

F5 = to store the number to memory no. 5

As a maximum 32 digits can be stored to memory # 5. Special characters can be entered with the following Fx codes:

pause **F0**

* **F7**

F8

Example: enter 7 0611 F9 1 1234 555 F80 F5 if the provider prefix is 0611, the Pager number 1234 and the message 555. Number 1 after F9 is a language selector, code F80 represents #0 = end of message.

*Note: some Paging providers also offer an option to send the message as an **SMS to the GSM network**. Consult your Paging provider for details if you have trouble sending a message to the Pager.*

To delete the Pager number enter:

7 F0 F5

If the memory number 5 is empty, no message will be sent to a Pager.

Factory default setting: all memories from 1 to 5 are empty.

9.2. Voice message recording

sequence: 8 0

Press shortly key **8** then press key **0** and hold it pressed while talking into the control panel's front grid (max. 20 seconds). After releasing the 0 key, the message will play back. The message is stored in non-volatile memory and can be changed when ever you want to by repeating the above steps. Make the message clear and brief. The dialer repeats the message to each called number for 40 seconds.

It is possible to **split the voice message into two different messages** (10 seconds each). Depending on the setting in section 9.5., a particular message will be sent under different situations.

If you want to **record two messages**: press shortly key **8** and then press key **1** and hold it pressed while recording the first message. To record the second message press shortly key **8** then press key **2** and hold it pressed while talking into the control panel's front grid.

9.3. Telephone dialer testing

sequence: 8 9

Enter **89** and the dialer will call the programmed numbers once. You will hear the telephone line signals from the built in speaker during the test (if the dialer is triggered by an alarm in normal operation, it will call silently). Testing can be terminated with the **N** key.

If two different voice messages were recorded, then use sequence 88 to test the sending of the first message and 89 to test the sending of the second message.

9.4. Dialing method

sequence: **9 0 x**

Enter:

9 0 1 for **tone** dialing

9 0 0 for **pulse** dialing (this option is blocked for some countries)

Note: this dialing method setting is also valid for Monitoring station communications as well as remote PC access

Factory default: tone dialing

9.5. Telephone dialer triggering*

sequences: **9 y x**

With sequences 91x to 95x you can select which alarms will trigger the telephone dialer to call and which ones will not.

Enter:

9 y x

where

y	alarm
1	Panic – silent
2	Intruder
3	Fire
4	Tampering
5	Technical trouble

x	reaction
0	not to call
1	voice message & Pager code
2	voice message only
3	Pager code only

Example: if the dialer should not call when the system is tampered with, enter 940

Factory default setting: all alarms will trigger the dialer (it means 911, 921, 931, 941 & 951)

If two different voice messages were recorded (see 9.2.), then parameter **x** specifies which message will be sent.

x	reaction
0	not to call
1	send message #1 and Pager code
2	send message #2 only
3	Send Pager code only

9.6. Telephone line checking

sequence: **9 9 x**

If this function is enabled, the dialer will check regularly if the telephone line is ready to make a phone call. If the line is not ready for more than 15 minutes, the control panel will indicate a telephone line failure (failure L). Not working telephone line or a phone conversation or Internet connection longer than 15 minutes can cause a fault.

options:

9 9 1 checking **enabled**

9 9 0 checking **disabled**

Note: this setting is also valid when the dialer is used for Monitoring station communications as well as remote PC access

Factory default setting: checking disabled

10. To enable a remote computer to dial in

When the user or installer wants to dial in to the installation from their JA-60U modem equipped computer or JA-60E keypad (see 15.), the following parameters should be programmed in the control panel's telephone dialer.

The most convenient programming of the dialer is via a connected PC using the Comlink software (see 14). Programming can also be performed by entering programming sequences from the system keypad while in the control panel programming mode:

- Enter the programming mode (entering **F 0 SC** - SC = Service Code, factory default SC=6060), indicated by a „P“ on the display. This can only be done while the panel is disarmed.
- The programming sequences can be entered from the keypad. Any unfinished sequence can be terminated by **N** key.
- **To exit the programming mode, press the N key** („P“ will turn off).

Dialing in parameters

Function	sequence	options	factory d.	note
Incoming call reaction	0 5 x	0=disabled, 1= second call, 2-6 = after ring No. 2 - No.6	disabled	
Remote access code (8 digits)	0 7 xxxxxxxx	any 8 digits code	00000000	

10.1. Reaction to an incoming call

sequence: 05

This sequence sets how the communicator will react to incoming calls on the telephone line. This setting is important for access from a remote computer.

0 5 x

x can be **0** - never answer

1 - answer after second call = after 1 or 2 rings are detected, there must be a pause of 10 - 45 seconds. The dialer will then answer on the very first ring of the second call. This setting can be used to bypass an answering or facsimile machine connected to the same line. This "Second Call" feature is supported by the Comlink software

2, 3, 4, 5, 6 - answer after 2nd, 3rd, 4th, 5th or 6th ring

Note: Remote access connection can also be enabled by the alarm system user (regardless of the above setting) by entering code 89 during service or user mode, when a remote call rings. If you use another telephone set on the same telephone line, it should be switched to a tone dial mode.

Factory setting: 0 = never answer

10.2. Remote access code setting

sequence: 07

In order to access the panel from a remote computer or JA-60E keypad, it is necessary to authorize the access with an 8-digit access code. This code is compared with the one programmed in the control panel. If the remote computer tries to access the panel with an other code, the connection will be terminated immediately and a wrong code alarm will triggered on the control panel. Store your access code to the control panels by entering:

0 7 xxxxxxxx

x x x - any 8 digits access code

Factory setting: 00000000

11. Factory default RESET

If you forgot the control panel codes or you have a control panel which is currently not under factory default setting, perform the following procedure:

- disconnect the AC adapter, back up battery and wait 30 seconds.
- reconnect the back up battery and close the control panel cover
- press and hold the 6 key on the control panel while reconnecting the AC adapter.
- when "—" is displayed, enter 060 (within 10 seconds)
- reset is confirmed with "P" (panel is in programming mode)

Note: this procedure resets the factory default settings (see table 8). The Master code will be 1234, Service code 6060 and all user codes, detectors, controllers and other enrolled items will be forgotten. All telephone numbers will be erased. The reset will not erase event memory and information about the reset will be recorded there.

Warning: if the Master code is forgotten when reset is disabled (with sequence 280 - see part 8.9.), the control panel reset will be possible only by the manufacturer.

12. Monitoring station communication setting

This part of the manual is intended only for the use of specialists involved in monitoring. We recommend to use a computer equipped with Comlink program for complete setting of the monitoring station communication (see 14). Changes of the setting can also be performed manually using the JA-60E or built in keypad of the JA-60 system:

- Enter the programming mode (entering **F0 SC** - SC = Service Code, factory default SC=6060), indicated by a „P“ on the display.
- **To exit the programming mode, press the N key** („P“ will turn off).

Monitoring station communication parameters

Sequence	Description	Factory default setting															
0 001 xx to 0 198 xx	Reporting codes table (see part 13) where: x = 0 – 9 , F0 = A_h , F1 = B_h , F2 = C_h , F3 = D_h , F4 = E_h , F5 = F_h if 00 is set, the event is not reported	00	For all events														
0 2 xxxx	Account code (4 digits, for 3/1 and 3/2 formats the structure is 0xxx) x = 0 – 9 (hexadecimal codes can be used too - see above)	0000															
0 3 xy	Protocol x : <table style="display: inline-table; vertical-align: top; margin-right: 20px;"> <tr><td>0 = Ademco Slow</td><td>5 = Radionics 1400</td></tr> <tr><td>1 = Ademco Fast</td><td>6 = DTMF 2300</td></tr> <tr><td>2 = Telex</td><td>7 = Surgard</td></tr> <tr><td>3 = Franklin</td><td>8 = Ademco Express</td></tr> <tr><td>4 = Radionics 2300</td><td>9 = Contact ID</td></tr> </table> Format y : <table style="display: inline-table; vertical-align: top;"> <tr><td>0 = 3/1 (xxx R)</td></tr> <tr><td>1 = 3/2 (xxx rc)</td></tr> <tr><td>2 = 4/1/1 (xxxx Rn)</td></tr> <tr><td>3 = 4/2 (xxxx rc)</td></tr> </table>	0 = Ademco Slow	5 = Radionics 1400	1 = Ademco Fast	6 = DTMF 2300	2 = Telex	7 = Surgard	3 = Franklin	8 = Ademco Express	4 = Radionics 2300	9 = Contact ID	0 = 3/1 (xxx R)	1 = 3/2 (xxx rc)	2 = 4/1/1 (xxxx Rn)	3 = 4/2 (xxxx rc)	90	Contact ID
0 = Ademco Slow	5 = Radionics 1400																
1 = Ademco Fast	6 = DTMF 2300																
2 = Telex	7 = Surgard																
3 = Franklin	8 = Ademco Express																
4 = Radionics 2300	9 = Contact ID																
0 = 3/1 (xxx R)																	
1 = 3/2 (xxx rc)																	
2 = 4/1/1 (xxxx Rn)																	
3 = 4/2 (xxxx rc)																	
0 4 x	Re-dialing pause, x = 1 – 9 (x 10 min.)	1	10 minutes														
0 6 xx..xFy	Phone numbers xx...x to memory y (1 and 2), pause = F0		erased														
0 9 6060	Communicator reset to factory default settings		-														

Dialing method (tone / pulse) and **telephone line checking** has a common setting with the voice & Pager message setting - see part 9.4. and 9.6.

Notes:

Some of the protocols are not standardized and some manufacturers of Monitoring Station receivers use different parameters in some of their protocols. Therefore Jablotron cannot guarantee full compatibility with all Monitoring Station receivers.

If the connection with the Monitoring Station is not available, the events are queued in the communicator's memory and are transmitted in one burst as soon as the connection is established. All events are reported to the Monitoring Station in the same order as they happened.

Once communication has started, it can not be interrupted unless the control panel is

switched to the programming or to the user mode. For example, if the user causes a false alarm and then cancels it, both events are sent to Monitoring Station.

Events occurring while the JA-60 control panel is in a programming or user mode are reported to the Monitoring Station after the closing of these modes. (They are stored in the memory and reported together with reporting codes describing the change of operation modes.)

When the dialer is activated, the communication to the monitoring station has the highest priority (voice and Pager messages are sent later with lower priority). A User or Installer can

interrupt the digital dialer communication by entering the User mode or Programming mode. Reset of the control panel has no influence to the digital communicator's settings (it is reported to the Monitoring station as an event).

The RESET of the digital communicator itself (sequence 0 9 6060), the change of the Monitoring Station's telephone numbers, the change of an account number code or the change of a format setting will erase all the reporting codes queued in the communicator's memory. However the events remain stored in the control panel's internal memory.

12.1. Reporting code setting

sequences: 00 and 01

These sequences can be used to program the reporting codes for all possible events. Depending on the used protocol and format, different amounts of data should be entered. The complete report codes programming table is shown in section 13. The setting sequence structure is as follows:

0 x x x r c

xxx = event number (from 001 to 198)

rc = report code (two digits). For 3/1 and 4/1/1 formats only the first digit of the reporting code is used (R). Codes should be entered in a hexadecimal format, with numbers higher than 9 beginning with the F key: **A_h = F0 B_h = F1 C_h = F2 D_h = F3 E_h = F4 F_h = F5**

If the reporting code 00 is programmed, the event will not be reported to the Monitoring Station.

Factory setting: 00 for all events

Notes:

- Abbreviation "Rc" is used in the report codes programming table for the major events group. Only the first digit of this group of codes is transmitted when formats 3/1 or 4/1/1 are used. Other formats use both digits of the "Rc" and "rc" report codes.
- The Contact ID (CID) is an automatic protocol. If you enter any report code other than zero for a major event (Rc), all events of this type will be transmitted automatically including all details regarding the event source. Internal structure of the CID protocol is shown in the part 13.1. This protocol provides the most in-depth data for the monitoring station and its use is recommended by Jablotron.
- The Surgard protocol has 4/2 structure plus one more digit which is generated automatically (see 12.3.)
- The pulse formats are not capable to report zone numbers above 15. For this reason events in zone 16 or in a subsystem are reported to the Monitoring Station as events in zone 10. This means that from the point of view of the monitoring station zone 10 also covers zone 16 and the subsystem if used. This problem does not exist in the CID protocol.
- If the control panel is split and only one section is armed, then a partial arming report code is sent. If all sections are armed, a complete arming report code is sent. If the system was completely armed and only one section is disarmed, will be sent the partial arming report code.
- If the system is arming while there is a bypass, partial arming will be reported to the CMS (also stored to the internal memory)

12.2. Account code setting

sequence: 02

This sequence is used for the alarm system identification by a Monitoring Station. The sequence structure is as follows:

02 x x x x

xxxx – account code (x are numbers from 0 to 9 or hexadecimals).

When using only three-digit codes (formats 3/1 and 3/2) enter a zero in the first position. The communicator will then ignore it (example - 0123)

Note: Changing of the account code erases the internal communicator's memory of non reported events and sends a „Reset“ reporting code (051) to the Monitoring Station.

Factory setting: 0000

12.3 Protocol and Format setting

sequence: 03

This sequence is used to select the communication protocol and format. Its structure is as follows:

03 x y

x - protocol (0 – 9, see table bellow)

y - format (0 - 3 see table on right)

Protocols						
x	Name	Hand-shake	Data	Kiss off	Speed	format
0	Ademco Slow (<i>Silent Knight</i>)	1400Hz	1900Hz	1400Hz	10bps	Next table
1	Ademco Fast	1400Hz	1900Hz	1400Hz	14bps	Next table
2	Telex	2100Hz	1650Hz	2100Hz	10bps	Next table
3	Franklin	2300Hz	1800Hz	2300Hz	20bps	Next table
4	Radionics 2300	2300Hz	1800Hz	2300Hz	40bps	Next table
5	Radionics 1400	1400Hz	1900Hz	1400Hz	40bps	Next table
6	DTMF 2300	2300Hz	DTMF	2300Hz	DTMF	Next table
7	Surgard*	2300Hz	DTMF	2300Hz	DTMF	4/3
8	Ademco express*	Dual tone	DTMF	1400Hz	DTMF	4ID/2
9	Contact ID*	Dual tone	DTMF	1400Hz	DTMF	CID

* fixed format, "y" is arbitrary (0 is recommended)

Notes:

1/ Some Monitoring Station receivers do not support all formats.

2/ Logic of the format marking - 4/2 means, that an account code has 4 digits and an event report code has 2 digits.

Changing of a format erases the internal communicator's memory of non reported events and sends a „Reset“ reporting code (051) to the Monitoring Station.

Factory setting: 90 (Contac ID)

Formats			
y	format	reports	structure
0	3/1	Major events only	xxx R
1	3/2	All events	xxx rc
2	4/1/1	Major events with autom. source identification	xxxx Rn
3	4/2	All events	xxxx rc

xxxx = account number

R = major event code (first digit counts only)

rc = detailed event code (two digits)

n = source identification (generated automatically)

Surgard protocol has structure: xxxx E rc, where E is a group identifier (generated automatically)

E	Event	Note
1	Fire	
2	Panic	
3	Alarm	General
4	Arming	Incl. Partial
5	Disarming	
6	Failure	Mains failure, RF jamming etc..
8	Report	Enter/Exit service mode ...
9	Restore	End of alarm, panic ...
A	Test	24 hour test

12.4. Re-dialing pause setting

sequence: 04

If a dialer is triggered it attempts to make a connection (altering the main and the backup telephone number). If it is not possible to make a connection after 8 attempts, a pause is inserted. After this pause the dialer dials again. If any event triggers the communicator during the pause, the pause ends immediately. The pause length can be set in a following way:

0 4 x

x – time multiplied by 10 minutes (from 1 to 9, example 3 = 30 minutes)

Factory setting: 1 = 10 min.

12.5. Phone number entering

sequence: 06

Monitoring station modem phone numbers can be stored by entering the following sequence:

0 6 x x x F y

xx...x - Monitoring Station phone number (up to 16 digits)

y is 1 for main phone number memory

2 for back up phone number memory

Pause (3 sec.) can be inserted into the telephone number by entering **F0**. It is also possible to insert the * tone by **F7** or the # tone by **F8** if requested for DTMF dialing.

Example: number 02 123456 as main Monitoring Station number is entered with 06 02 F0 123456 F1.

Phone number erasing

0 6 F 0 F y

y is 1 to erase the main telephone number

2 to erase the back up telephone number

Note: Changing of a phone number erases the internal communicator's memory of non reported events and sends a „Reset“ reporting code (051) to the Monitoring Station.

Factory setting: both numbers are erased

12.6. Digital communicator reset

sequence: 096060

By entering this sequence the factory default settings of all parameters are restored. All phone numbers, reporting codes, account codes etc. are erased. This reset doesn't effect the voice dialer's settings. The reset sequence is:

0 9 6060

Note: All communicator settings are normally stored in non-volatile memory and remain unchanged even after switching off the power supply.

13. Monitoring station reporting codes table

A two digit reporting code **rc** (00 to FFh) can be set for every event. If 00 is programmed as a report code, that event will not be reported.

The major events group is marked with **Rc**. When formats 3/1 or 4/1/1 are used, only these major events are reported to the Monitoring Station. This makes it necessary to only program the **R** digits. The second digit does not count.

For Contact ID protocol, program code 11 for major events (**Rc**) which you want to report and the system will generate all details regarding the event automatically.

N.	Event	Code
001	Arming with remote control N.1	Rc
002	Arming with remote control N.2	rc
003	Arming with remote control N.3	rc
004	Arming with remote control N.4	rc
005	Arming with remote control N.5	rc
006	Arming with remote control N.6	rc
007	Arming with remote control N.7	rc
008	Arming with remote control N.8	rc
009	Arming with master code	rc
010	Arming with user code N.1	rc
011	Arming with user code N.2	rc
012	Arming with user code N.3	rc
013	Arming with user code N.4	rc
014	Arming with user code N.5	rc
015	Arming with user code N.6	rc
016	Arming with user code N.7	rc
017	Arming with user code N.8	rc
018	Arming with user code N.9	rc
019	Arming with user code N.10	rc
020	Arming with user code N.11	rc
021	Arming with user code N.12	rc
022	Arming with user code N.13	rc
023	Arming with user code N.14	rc
024	Partial arming	Rc
025	Quick arming without code	Rc
026	Disarming with remote control N.1	Rc
027	Disarming with remote control N.2	rc
028	Disarming with remote control N.3	rc
029	Disarming with remote control N.4	rc
030	Disarming with remote control N.5	rc
031	Disarming with remote control N.6	rc
032	Disarming with remote control N.7	rc
033	Disarming with remote control N.8	rc
034	Disarming with master code	rc
035	Disarming with user code N.1	rc
036	Disarming with user code N.2	rc
037	Disarming with user code N.3	rc
038	Disarming with user code N.4	rc
039	Disarming with user code N.5	rc
040	Disarming with user code N.6	rc
041	Disarming with user code N.7	rc
042	Disarming with user code N.8	rc
043	Disarming with user code N.9	rc
044	Disarming with user code N.10	rc
045	Disarming with user code N.11	rc
046	Disarming with user code N.12	rc
047	Disarming with user code N.13	rc
048	Disarming with user code N.14	rc
049	Entering of the programming mode	Rc
050	Exiting the programming mode	Rc
051	Communicator Reset	Rc
052	Initial AC powering	Rc
053	Alarm after initial AC powering	Rc
054	General battery trouble	Rc
055	General battery trouble end	Rc
056	Control panel battery trouble	Rc
057	Control panel battery trouble end	Rc
058	Zone alarm 1	Rc
059	Zone alarm 2	rc
060	Zone alarm 3	rc
061	Zone alarm 4	rc
062	Zone alarm 5	rc
063	Zone alarm 6	rc
064	Zone alarm 7	rc
065	Zone alarm 8	rc
066	Zone alarm 9	rc
067	Zone alarm 10	rc
068	Zone alarm 11	rc
069	Zone alarm 12	rc
070	Zone alarm 13	rc
071	Zone alarm 14	rc
072	Zone alarm 15	rc
073	Zone alarm 16	rc
074	Wrong access code alarm	Rc
075	Zone tamper 1	Rc
076	Zone tamper 2	rc
077	Zone tamper 3	rc
078	Zone tamper 4	rc
079	Zone tamper 5	rc
080	Zone tamper 6	rc
081	Zone tamper 7	rc
082	Zone tamper 8	rc
083	Zone tamper 9	rc
084	Zone tamper 10	rc
085	Zone tamper 11	rc
086	Zone tamper 12	rc
087	Zone tamper 13	rc
088	Zone tamper 14	rc
089	Zone tamper 15	rc
090	Zone tamper 16	rc
091	Keypad tamper	rc
092	Control panel tamper	rc
093	Siren tamper	rc
094	Zone fault 1	Rc
095	Zone fault 2	rc
096	Zone fault 3	rc
097	Zone fault 4	rc
098	Zone fault 5	rc
099	Zone fault 6	rc
100	Zone fault 7	rc
101	Zone fault 8	rc
102	Zone fault 9	rc
103	Zone fault 10	rc
104	Zone fault 11	rc
105	Zone fault 12	rc
106	Zone fault 13	rc
107	Zone fault 14	rc
108	Zone fault 15	rc
109	Zone fault 16	rc
110	Keypad fault	rc
111	Control panel fault	rc
112	Siren fault	rc
113	Zone alarm end 1	Rc
114	Zone alarm end 2	rc
115	Zone alarm end 3	rc
116	Zone alarm end 4	rc
117	Zone alarm end 5	rc
118	Zone alarm end 6	rc
119	Zone alarm end 7	rc
120	Zone alarm end 8	rc
121	Zone alarm end 9	rc
122	Zone alarm end 10	rc
123	Zone alarm end 11	rc
124	Zone alarm end 12	rc
125	Zone alarm end 13	rc
126	Zone alarm end 14	rc
127	Zone alarm end 15	rc
128	Zone alarm end 16	rc
129	Zone tamper end 1	Rc
130	Zone tamper end 2	rc
131	Zone tamper end 3	rc
132	Zone tamper end 4	rc
133	Zone tamper end 5	rc
134	Zone tamper end 6	rc
135	Zone tamper end 7	rc
136	Zone tamper end 8	rc
137	Zone tamper end 9	rc
138	Zone tamper end 10	rc
139	Zone tamper end 11	rc
140	Zone tamper end 12	rc
141	Zone tamper end 13	rc
142	Zone tamper end 14	rc
143	Zone tamper end 15	rc
144	Zone tamper end 16	rc
145	Keypad tamper end	rc
146	Control panel tamper end	rc
147	Siren tamper end	rc
148	Zone fault end 1	Rc
149	Zone fault end 2	rc
150	Zone fault end 3	rc
151	Zone fault end 4	rc
152	Zone fault end 5	rc
153	Zone fault end 6	rc
154	Zone fault end 7	rc
155	Zone fault end 8	rc
156	Zone fault end 9	rc
157	Zone fault end 10	rc
158	Zone fault end 11	rc
159	Zone fault end 12	rc
160	Zone fault end 13	rc
161	Zone fault end 14	rc
162	Zone fault end 15	rc
163	Zone fault end 16	rc
164	Keypad fault end	rc
165	Control panel fault end	rc
166	Siren fault end	rc
167	Telephone line trouble	Rc
168	Telephone line trouble end	Rc
169	Control panel failure	Rc
170	End of control panel failure	Rc
171	Periodic test (24 hr. from last com.)	Rc
172	AC failure (in 30 min. after failure)	Rc
173	AC failure end	Rc
174	RF jamming	Rc
175	Wrong code alarm end	Rc
176	RF jamming end	Rc
177	Panic alarm from remote control N.1	Rc
178	Panic alarm from remote control N.2	rc
179	Panic alarm from remote control N.3	rc
180	Panic alarm from remote control N.4	rc
181	Panic alarm from remote control N.5	rc
182	Panic alarm from remote control N.6	rc
183	Panic alarm from remote control N.7	rc
184	Panic alarm from remote control N.8	rc
185	Master code panic alarm	rc
186	User code panic alarm	rc
187	Panic alarm end from remote contr. 1	Rc
188	Panic alarm end from remote control N.2	rc
189	Panic alarm end from remote control N.3	rc
190	Panic alarm end from remote control N.4	rc
191	Panic alarm end from remote control N.5	rc
192	Panic alarm end from remote control N.6	rc
193	Panic alarm end from remote control N.7	rc
194	Panic alarm end from remote control N.8	rc
195	Master code panic alarm end	rc
196	User code panic alarm end	rc
197	Subsystem panic alarm	Rc
198	Subsystem panic alarm end	Rc

13.1. Internal structure of Contact ID protocol

The data in the CID protocol has following structure:

XXXX 18 Q XYZ 01 CCC

where XXXX is the account code of the installation, 18 is the code identification (identical for all events), Q is a number from 1 to 3, XYZ is the event number, 01 is the subsystem number, CCC event source details (see the table down the page).

JA-60 event no.	Q XYZ	Event description	possible source in JA-60						
			C	S	c	A	J	L	d
058	1 110	Fire alarm		✓			✓		
113	3 110	Fire alarm end		✓			✓		
177	1 120	Panic alarm	✓		✓				✓
058	1 120	Panic alarm from a detector		✓					
197	1 120	Panic alarm in the subsystem					✓		
187	3 120	End of the panic alarm	✓		✓				✓
113	3 120	End of the panic alarm from a detector		✓					
198	3 120	End of the subsystem panic alarm					✓		
058	1 130	Intruder alarm in an instant zone		✓					
113	3 130	End of the intruder alarm in an instant zone		✓					
058	1 134	Intruder alarm in a delayed zone		✓					
113	3 134	End of the intruder alarm in a delayed zone		✓					
075	1 137	System tamper alarm	✓		✓	✓	✓		✓
129	3 137	All system tampers OK	✓		✓	✓	✓		✓
074	1 138	Wrong access code alarm	✓		✓				✓
175	3 138	End of a wrong access code alarm	✓		✓				✓
053	1 140	Alarm after powering of the control panel	✓						
075	1 144	Detector tamper alarm		✓					
129	3 144	All detector tampers OK		✓					
094	1 300	Failure (blown fuse in control panel or other general failure)	✓		✓	✓	✓	✓	✓
052	3 300	Control panel powering	✓						
148	3 300	No failure in the system	✓		✓	✓	✓	✓	✓
172	1 301	AC failure	✓						
173	3 301	AC switched on	✓						
054	1 302	Problem with power in an item			✓	✓	✓		
056	1 302	Back up battery failure in the control panel	✓						
057	3 302	End of the back up battery failure	✓						
055	3 302	End of the problem with power in the item			✓	✓	✓		
051	1 305	Reset	✓						✓
049	1 306	Entering of programming or user mode	✓		✓				✓
050	3 306	End of programming or user mode	✓		✓				✓
058	1 330	Subsystem alarm					✓		
167	1 354	Tel. line failure							✓
169	1 354	Failure of communication in the digital bus							✓
168	3 354	End of tel. line failure							✓
170	3 354	End of a communication failure in the digital bus							✓
174	1 355	RF jamming	✓						
176	3 355	End of RF jamming	✓						
094	1 380	Detector failure		✓					
148	3 380	End of all detector failures		✓					
094	1 381	Wireless item communication lost		✓	✓	✓	✓		
148	3 381	Wireless item communication reestablished		✓	✓	✓	✓		
054	1 384	Detector power problem		✓					
055	3 384	End of the detector power problem		✓					
026	1 401	Disarming	✓		✓				✓
001	3 401	Complete arming	✓		✓				✓
024	3 402	Partial (Home) arming	✓		✓				✓
025	3 408	No code arming	✓		✓				✓
171	1 602	Monitoring station communication testing (in 24 hr.)							✓

Event sources specification in the Contact ID protocol:

JA-60 source	mark	code CCC
Wireless sensor	S	001 to 016
Controller	c	401 to 408
User code		501 to 514
Control panel	C	701
Wireless siren	A	711
Sub control panel	J	721
Tel. Line	L	731
Digital bus	D	741


14. Personal Computer Interface with JA-60

The JA-60 system can be connected to a Personal Computer (PC) locally, using the PC-60A interface cable. It is also possible to dial into the system from a remote PC (or the JA-60E keypad) using the JA-60U modem (see 15). Comlink software is available for Windows system.


User can check and operate the JA-60 system easily via their PC, can read complete events memory with all details, can view the map of the installation (seeing topical triggering of the detectors) etc. However, the user can not change settings of the system.

Installer who has access rights can program the system, can check the communication quality of the items, can view the level of interference in the location etc. There is also a convenient tool to make a map of the installation, which includes a library of all JA-60 components.


Depending on your access rights, the Comlink software will allow you to open the corresponding screens (see following examples). There is a clear help in the Comlink program.




"virtual" control panel & complete events list



items testing window & RF signals oscilloscope



programming dialogs



map of the system (shows current conditions in the house)

15. Remote access to the system

The JA-60U modem is used for the remote connection of a personal computer with Comlink software or a JA-60E keypad to a JA-60 control panel using a public telephone line. It is necessary to know the access code for the remote control of a system (see 10.2).


It enables a computer to remotely control a JA-60 in the same way as when it connected directly to the JA-60 PC's output (see 19). Downloading or uploading of extensive data (like event list downloading, digital communicator setting etc.) takes more time compared to a direct PC connection to the control panel. Instructions about JA-60E remote access you can find in the JA-60E manual.

15.1. Establishing connection with a remote control panel by a computer

Start Comlink SW on a computer equipped with a JA-60U modem (see 19). The dialing dialog requires the following data:

- telephone number of the called control panel
- dialing method (tone or pulse)
- COM port number to which the modem is connected
- control panel's remote access code (must be identical as code programmed in the control panel - 8 digits)
- select bypassing of answering machine (if this option was programmed in the control panel)
- select call back feature and enter your telephone number, if you want the control panel to call your computer back (that way the end user's telephone line will be charged for the remote access communication)

See the JA-60E keypad's manual for details how to establish connection from a remote keypad.



"Dialing in" dialog of the Comlink Windows software

16. Recommended Professional installer basic rules

If you install the system for a customer, you should follow these rules:

- make a drawing of intended location of the items, keeping in mind proper protection for the intended area.
- if the customer requests reduction of the system (price reasons etc.), ask for a written confirmation that he does not want the particular items you recommended (to avoid blame and liability if poorly covered area is robbed in the future)
- make a professional installation and do not forget to clean and be tidy.
- it is very important to explain to the customer all functions of the system, to teach to him or her how to program access codes, how to test the system and how to replace batteries in the items
- offer your regular assistance for testing and battery replacement (we recommend annually)


make a written report signed by the customer, that the installation was finished properly and that she or he received your training on how to operate and test the system

17. Trouble shooting table

Problem	possible cause	solution
alarm after first powering of the control panel	the control panel is not in factory default setting	perform a factory default reset, see 11
impossible to enroll a detector or a keypad	location of the item (or the control panel) is not suitable and the radio signal level is too low (too far away or an obstacle is in the way of communication)	change location of the item, (fix it in the new place temporary at first and then try it)
a fault is indicated on the control panel and it is beeping	check display for the reason of the trouble. Press key N to disable beeping. The trouble information is stored in the event memory and it can be reviewed entering F4 anytime in the future	check the reason of the trouble in user instructions and fix it, or call the installer
telephone line failure is indicated and the phone works as normal	when you make a phone call longer than 15 minutes, it is interpreted by the system that the tel. line is not ready.	if this problem repeats, disable tel. line checking in programming mode
JA-60P movement detector repeatedly triggers alarms with no visible reason	check if there are: animals in the protected area (mice...), sudden changes of temperature or intense air circulation, movement of objects with temperature of about 37°C etc.	increase detector's immunity (DIP SW 1 to pos. ON), change location of the detector or use an optional sensor's lens
fault C is indicated on the control panel	technical problem of the control panel – failure of the power supply, blown fuse in the panel etc.	check AC adapter, backup up battery, fuses or call installer
when activated, the tel. dialer calls a number multiple times	the telephone network (mobile network) does not use standard recognition signals and the dialer is not sure if the connection was successful or not	for calls to GSM network store F0 after the last digit to the number (see 9.1.)
alarm C is indicated on the control panel	jammed communication or blown fuse in the control panel	the jamming check can be disabled if necessary
system does not communicate with connected PC	the data cable is not connected to the correct connector on the PC	check the connection or select the port number in SW manually
problem is not in this list	call installer or the distributor for advice	local hot line number:

18. Possibilities to extend the system

The JA-60 alarm system is a kit which can be tailor configured according to the size of the house or the needs of the user. See the structure of the system:



18.1 Extension of the system with a subsystem

An additional JA-60 or 65 control panel can be enrolled as a subsystem to the control panel (see 8.10.). Each system then works as an independent system. However, any event in the subsystem (alarm, tampering, failure or low battery) will trigger the same kind of event on the main control panel (the main control panel will display "J" as the event source). The main control panel will not indicate the number of the item which triggered the event, but this information is available on the subsystem's control panel.

Using this method, multiple level subsystems can be chained.

19. Overview of the JA-60 parts

The following description includes the basic assortment of accessories. Jablotron is systematically introducing new and improved JA-60 items to the market. You can get the most current information from your distributor or you can visit Jablotron's Internet home page at: www.jablotron.com

Detectors

JA-60N Magnetic door detector - is equipped with a magnet. Movement of the magnet triggers the internal sensor in the detector. It can trigger an Instant or Delayed intruder alarm and it also has built in tamper detectors. There are inputs for external sensors (see section 7.2. for more details).



power
battery life time
communication range
working environment
built in sensor
external sensors inputs

3 V₊, 30 μA / 100 mA (2x AAA battery 1,5 V)
about one year
max. 100 m (open area)
indoor use (-10 to +40 °C)
magnetic reed contact
IN & TAMP (balanced loops)

JA-60P Motion detector - triggers an Instant or Delayed intruder alarm when the movement of a human body is detected. It has built in tampering sensors and it uses digital processing of the signal for a high false alarm immunity. Optional lenses (long corridor, pet zone) are available for this detector.



power
battery life time
communication range
working environment
detection method
installation height
coverage

3 V₊, 35 μA / 100 mA (2x AAA battery 1,5 V)
about one year
max. 100 m (open area)
indoor use (-10 to +40 °C)
dual PIR sensor with digital processing
from 2 to 2,5 meters
12m / 120° (with basic lens)

JA-60B Glass break detector - is a modern acoustic device, which performs continuous air pressure and sound analysis to recognize the breaking of a window. Digital processing provides high reliability and false alarm immunity.



power
battery life time
communication range
working environment
detection method
detection range

3 V₊, 40 μA / 100 mA (2x AAA battery 1,5 V)
about one year
max. 100 m (open area)
indoor use (-10 to +40 °C)
dual digital analysis of acoustic signals
max. 9m

JA-60SR Ionisation smoke detector - The JA-60SR detects smoke and wirelessly transmits this information to a receiving unit (control panel). It also has a built in siren to warn people in the immediate vicinity. For testing purposes the detector is equipped with a testing button. You can also test it remotely using any audio/video remote control.



power
battery life time
communication range
working environment
detection method
built in siren

3 V₊, 30 μA / 100 mA (2x AAA battery 1,5 V)
about one year
max. 100 m (open area)
indoor use (-10 to +60 °C)
ionic chamber
95 dB/m A (85 dB/3m)

JA-60SP Optical smoke detector - The JA-60SP detects smoke and wirelessly transmits this information to a receiving unit (control panel). It also has a built in siren to warn people in the immediate vicinity. For testing purposes the detector is equipped with a testing button. You can also test it remotely using any audio/video remote control.



power
battery life time
communication range
working environment
detection method
built in siren

3 V₊, 30 μA / 100 mA (2x AAA battery 1,5 V)
about one year
max. 100 m (open area)
indoor use (-10 to +60 °C)
IR light detection
95 dB/m A (85 dB/3m)

JA-60G Gas leak detector - triggers a Fire alarm when any combustible gas is detected (natural gas, city gas, propane, butane etc.). The detector is powered directly from the AC power network and it wirelessly transmits information to the control panel. The JA-60G has a built in siren and an output relay. The relay, for example, can be wired to an electrical valve to turn off the gas supply when a leak is detected.



<i>power</i>	230V(+10 to -15%) / 50Hz, about 2W
<i>2 sensitivity levels:</i>	10% and 20% of LEL (calibrated for Methane) LEL = Low Explosivity Level
<i>built in siren</i>	94 dB / 0.3 m
<i>output relay</i>	selectable reaction for 1 st or 2 nd level
<i>relay contact</i>	max.230 V / 5 A
<i>working environment</i>	indoor use (-10 °C to +40°C)
<i>detection method</i>	catalytic oxidation
<i>communication range</i>	max. 50 m (open area)

Controllers



RC-11 Remote control - this key chain tag sized controller can be used to Arm and Disarm the system. It can also be used to trigger a silent Panic alarm. It is powered by 6V battery and its working range is up to 30 meters. The RC-11 can also be used separately to control UC receiving modules directly (pulse, latch or ON and OFF modes).

RC-22 Panic button - is a large size button, which can be easily attached in a selected location (under a desk, on the wall etc.). This button can be used to trigger a silent Panic alarm. The RC-22 can be enrolled to the control panel the same way as the remote control. It has a working range up to 30 meters. The RC-22 can also be used separately to control UC receiving modules directly (pulse, latch or ON and OFF modes).



RC-40 Remote control - combines two pairs of buttons (A&B and 1&2). It can be used to operate multiple wireless Jablotron devices. For example, one RC-40 can control your car alarm and your house alarm system or two independent partitions in a house alarm or up to 6 different devices when used with Jablotron UC receivers. It has a unique optional "keypad locking" feature. It is powered by a 6V battery and its working range is up to 30 meters.



RC-60 Remote control – controls wirelessly the system by using other hardwired devices (access systems, ID chips, cards reader etc.). It has two control inputs (A and B) and two working modes. In the first mode input A arms and input B disarms the central unit. In the second mode input A responds on every impulse by sending arming or disarming signal. Input B responds on each connection to GND by PANIC signal transmission. It is powered by two batteries type AAA, lifetime of the batteries 1 year, range up to 100 m, for indoor use.

JA-60D Wireless control keypad - can operate the system in a similar way as the built in keypad on the control panel (arming, disarming, no code arming, partial arming, door opening and under duress operation). It has its own Master code and one User code, which can be programmed arbitrary from the control panel's codes.



<i>power</i>	3 V=, 30 µA / 100 mA (2x AAA battery 1,5V)
<i>battery life time</i>	about one year
<i>communication range</i>	max. 100 m (open area)
<i>working environment</i>	indoor use (-10 to +40 °C)
<i>codes</i>	1x Master, 1x User

JA-60E Wire operated keypad - can operate and program the system in exactly the same way as the built-in keypad on the control panel. It is connected to the control panel by a cable. Up to two keypads can be connected to a single control panel. The alarm system's status is indicated by the LED indicators, the built in display and built in buzzer. Illuminated keys can be covered with a closable cover. The keypad can control the system remotely when using the JA-60U modem.



<i>connection</i>	with cable to the JA-60 digital bus connector
<i>connecting cable</i>	4 core cable with RJ connectors (4/4 1:1) or ordinary telephone cable (terminals)
<i>length of the cable</i>	max. 100 m
<i>power supply</i>	10 – 14 V (taken from the digital bus)
<i>number of keypads in a system</i>	max. 2
<i>working environment</i>	indoor use (-10 to +40°C)

JA-60F Wireless keypad - can operate system in exactly the same way as the built-in keypad on the control panel. It can also be used for programming and testing of the system. The alarm system's status is indicated by the LED indicators, the built in display and

built in buzzer. Illuminated keys can be covered with a closeable cover. The keypad has TWO-WAY communication with the control panel and it is enrolled as a controller (positions c1 to c8). Multiple JA-60F keypads can be enrolled to a single control panel.



power
battery life time
communication range
working environment
optional AC adapter
number of keypads in a system

3 V₌, 50 μA / 100 mA (2x AAA battery 1,5V)
about one year
max. 100 m (open area)
indoor use (-10 to +40 °C)
12V ss/100mA (permanent keys illumination with the adapter)
up to total number of 8 controllers

Output devices

Wireless siren JA-60A is designated for outdoor use. It is powered from its own AC adapter and it has a built in back up battery. The siren wirelessly communicates with the control panel. It contains a high powered siren and a flashing light. Besides signaling alarms, it can also provide arming and disarming chirps. The siren has built in tamper detectors. Only one JA-60A siren can be used with each JA-60 control panel.



power
back up battery
communication range
siren
cover class
working environment

15V~, 0,5 A, 50 Hz (adapter SELV)
6V, 1.3Ah (included) - life time about 5 years
max. 100 m (open area)
piezoelectric, 118dB/1m
IP44
external use, -25 to +60°C

The AN-01 external antenna can be used with the siren if a longer working range is requested or if the siren is installed in a problematic location from the point of radio communication.

Wireless acoustic indicator UC-260 is an indoor device which can be easily plug to the power anywhere in the house. It receives signals from the control panel and generates all sounds as the system itself (siren, exit entrance beeps etc.). Its LED indicator is following the PgY output of the control panel. Additionally it can also serve as a wireless door bell (with RC-22 or RC-28 wireless button) and JA-60 wireless detector(s) can be enrolled to generate Chime sound when the detector is triggered.



Power
Communicating range
Siren
Number of melodies
Working environment

230 V~, 1.5 W
up to 100 m
piezo 110dB
8, selectable volume
indoor use -10 to +40°C

Wireless outputs unit UC-216 is a receiver, which receives signals from the JA-60 control panel. The unit has two output relays (X and Y, max. load 120V / 1A each). These relays have identical functions as outputs PgX and PgY of the control panel. The unit requires external power from 12 to 24VDC or 15VAC. Multiple UC-216's can be used with a control panel and each UC-216 can receive signals from more than one control panel.



power
2x output relay
1x output transistor
communication range
working environment

12-24 V₌ or 15 V~, 40 mA
max. 120 V/1 A
max. 40 V/0,2 A
with RC-11 & RC-22 max. 30 m
with JA-60 items up to 100 m
indoor use (-10 to +40 °C)

Wireless output unit UC-222 is a receiver, which receives signals from the JA-60 control panel. The unit has a power output relay (max. 250VAC / 5A). This relay has an identical function as output PgX of the control panel. The unit is powered directly from the AC power (230 VAC). Multiple UC-222's can be used with a control panel and each UC-222 can receive signals from more than one control panel.



power
consumption
output relay
communication range
working environment

230 V~
1 VA (0,6 W) standby / 1,8 VA (1 W) relay on
max.6 A, 250 V
with RC-11 & RC-22 max. 30 m
with JA-60 items up to 100 m
indoor use (-10 to +40 °C)

Use of UC-216 and UC-222 directly with JA-60 detectors - the wireless output modules can also be used directly with JA-60 system items (detectors, keypads, remote controls). In this case the receiving unit reacts to the signals from the items which were enrolled to this unit. The item can be a part of the JA-60 alarm system and its data is received by both the control panel and the UC receiver. Or, the items can be used with UC units directly.

Telephone dialer module JA-60X - the control panel is available without the dialer (model JA-60K) or with the built in dialer (model JA-60KX). The JA-60X dialer module can be easily installed to a JA-60K control panel as an after market accessory. The dialer can send a voice message(s) to four telephone numbers and it can also send a numeric message to a Pager. The dialer regularly checks if the telephone line is ready, yet allows the line to be used as a normal phone line inside the house. The dialer can also communicate with a monitoring station or with a remote PC. The dialer is designed for ordinary analog telephone line (TNV-3 type).



PC interface cable PC-60A - can be used to connect the control panel to a serial port (COM1 or COM2) in your computer. Suitable SW, ComLink, is provided on a floppy disk or you can visit Jablotron's Internet home page at: www.jablotron.com to download a beta version of it. The software is a convenient way to setup the control panel, to supervise the system which is on line, to read, view and store data from the event memory and to record other information about the system. The software can be installed under MS DOS or Windows system (see 14).

You can learn more about the SW features, when you install it on your computer. Even without the PC-60 interface cable you will be able to run the software in its off-line mode. The software has a built in help section.

It is possible to dial in to the control panel from a remote computer equipped with **JA-60U modem** and Comlink software. Instead of a computer, the JA-60E system keypad can be used, too. Installers mostly use the modem, but end user can use it as well (e.g. for remote arming and disarming etc.). The JA-60U is supplied together with power adapter, PC interface cable and Comlink software. The JA-60E keypad can be plugged directly to the data connector of the modem.