



AS-1 acoustic indicator

The **AS-1 acoustic indicator** is used for signalling the **reverse motion of a car**. It is connected to the drive backwards light of a car.