



## AS-1 Acoustic indicator

The **AS-1 acoustic indicator** is used for signalling the **reverse motion of a car**. It is connected to the drive backwards light of a car.

### Technical specifications

<b>Power</b>	12 - 30 V
<b>Interrupt frequency</b>	3 Hz +/- 30 %
<b>Sound frequency</b>	3 +/- 0,5 kHz
<b>Max. sound power</b>	85 dB/2 m
<b>Max. power consumption</b>	65 mA
<b>Operating temperature</b>	-20°C to + 60°C