



## PS-062A II Parking sensor

The PS-062A II parking sensor helps parking by informing the driver of obstacles behind or in front of the vehicle.